


Resource
Data Management

Intuitive Superpack Controller

Commissioning/User Guide
Revision 4.3



PR0650-SUP

Contents

- The Intuitive Range 4
 - Description 4
 - Configuration - Types 4
 - Quick Start Guide (using a PC) 5
 - Front Display Panel 6
 - Remote Display (PR0620) 6
 - Touch XL 7
- Intuitive Plant Controller I/O Connections 8
 - Mini I/O Connections 9
 - Universal Analogue Input / Output Connections 9
- Inputs & Outputs 9
- Setting up the controller 10
- Recommended set-up method 10
 - Set-up through front buttons 10
 - Display (PR0620) Menu Structure 11
 - Main Menu Overview (PC Connection) 12
 - Set/ View Probe Types & Units 14
 - Set/ View Pressure Units 14
 - Type. Set/ View controller type 14
 - Set/ View Number of Sections 14
 - Set/ View Number of Udev Devices 14
 - View Number of Expansion Boards 14
 - rtc. Real time clock 15
 - IP Network Configuration 15
 - IP-L 15
 - IP-r 16
 - Broadcast 16
 - USB Operation 16
- PArA. Set/view parameters 17
 - Section 1, 2, 3 Parameter table (d-01/ Sections) 17
 - Current Transformer Parameters (d-02/ CT Monitor - UDev) 22
 - Pressure, Probe, Status, Inverter and Relay Position Parameters (d-03/ Mapping - IOMap) 22
 - Universal I/O, Status Inputs, Invert Relays, Probe Offsets Configuration (d-04/ Hardware - Main Board) 23
 - Universal I/O, Status Inputs, Invert Relays, Probe Offsets Configuration (d-05/ Hardware - Ext Board) 23
 - Compressor Run Hours and Compressor Starts (d-06/ Stats) 23
- Parameter Descriptions 24
 - Section Parameters Description (d-01/ Sections) 24
 - Current Transformer Parameters Description (d-02/ CT Monitor - UDev) 28
 - Pressure, Probe, Status, Inverter and Relay Position Parameters Description (d-03/ Mapping - IOMap) 28
 - Universal I/O, Status Inputs, Invert Relays, Probe Offsets Configuration Description (d-04/ Hardware - Main Board) 28
 - Universal I/O, Status Inputs, Invert Relays, Probe Offsets Configuration Description (d-05/ Hardware - Ext Board) 29
 - Compressor Run Hours and Compressor Starts Description (d-06/ Stats) 29
- Using a Digital Scroll Compressor 30
- Liquid Level 30
- Run-Proof 31
- Gas Dump 31
- Compressor Loaders 32
- Equal Run Times 32
- Fan Reversal 33
- Inverter Bypass 33
- Relay Run Hours and Relay Starts 34
- Setup via a PC 35
 - Home page 35
 - Control 36
 - Alarms 36
 - Ct Monitor 37
 - Mapping 38
 - IO Mapping 39
 - Stats 1-3 40
 - Visibility 40
 - Hardware 41
 - Override Status 42
 - Mapping Summary 43
 - System 44
 - Network 45
 - Layout 46



Please ensure all power is switched off before installing or maintaining this product.

- Maintenance47
- Configuration of inputs and outputs48
- Status Inputs48
- External Target.....49
 - Pack Controller49
 - Condenser Controller Heat Reclaim.....49
 - Remote TDB Command for Heat Reclaim.....49
- Section Stages50
- Stage Sizes50
- Operation (Fuzzy)50
- Operation (Staged)51
- Other operational features51
 - Floating Head Pressure51
 - Drop Leg Control.....52
 - Night Set-back.....52
 - Day Set-back.....52
 - Invert Relays.....52
 - Sticky Fans.....53
 - Remote Relay53
- Viewing Inputs and Outputs54
 - Input/ Output table (d-01/ Sections)54
 - Input/ Output table (d-02/ CT Monitor - UDev)55
 - Input/ Output table (d-03/ Mapping - I/O Map).....55
 - Input/ Output table (d-04/ Hardware - Main Board).....55
 - Input/ Output table (d-05/ Hardware - Expansion Boards).....56
 - Input/ Output table (d-06/ Stats)56
- Quick View (PR0620 Remote Display).....56
- Info Button (PR0620 Remote Display)56
- Display Messages.....57
- Override Function57
 - Overrides - PR0620 Remote Display57
 - Overrides - LCD in-built Display58
 - Overrides - Touch Display58
- Standby Mode58
- Network Alarms.....58
- Specification59
 - Power requirements (for each Main Controller or expansion module)59
 - General.....59
 - Inputs.....59
 - Outputs59
 - Comms60
 - CANbus cable specification60
- Installation61
 - Mounting on to a DIN rail, Intuitive Plant Controller61
 - Clearances61
 - Cleaning62
- Appendix 1 – Supply & Status Input Wiring63
- Appendix 2 – Data Manager Load Shedding Setup63
- Appendix 3 – BACnet object list.64
- Revision History65



Please ensure all power is switched off before installing or maintaining this product.

The Intuitive Range

From Resource Data Management

This documentation refers to the Intuitive Super Pack Controller.

Description

This is a versatile controller intended for up to 3 sections of Pack and/or Condenser control. Each of the 3 sections has up to 16 relay outputs that are configurable for compressors, loaders, trim compressors, digital scroll compressors or fans. Each section has up to 16 status inputs that can be assigned to various purposes, such as compressor or fan faults or general alarms. Each section has three analogue (mA or dc volts) inputs for pressure transducers and/or a liquid level sensor. The Pressure readings obtained from Sections 1, 2 and 3 can be broadcast over a Data Manager's IP network for use by RDM Mercury Switches (PR0018-PHI). Each section has up to 8 temperature probe inputs and 1 analogue output (mA or dc volts) that can be used to control a variable speed device. There are 8 software type options, see [configuration](#) table below.

The "Fuzzy" based algorithm, will give enhanced control whilst maintaining the starts per hour requirement. This algorithm also reduces the number of parameters required for control thus reducing commissioning time.

Note: In fuzzy logic, if an inverter is being used, it is not included in the anti-short cycle timer (Starts per hour P-23) but has its own anti-short cycle timer (P-22).

The "Staged" type allows the user to fully program the output stages to the desired elements but requires the user to enter more parameters.

Up to 10 expansion modules (IO expansion, Mini IO expansion) can be connected to the controller to expand the number of inputs and outputs available to match a specific requirement, for example if each of the 3 sections has 16 compressor relays, then a minimum of 48 relays would be required (the main controller has 12 relays).

The Plant controller has an embedded Ethernet port to allow for connection to an RDM Data Manager system using standard IP, or a third party system using BACnet over IP. BACnet communications is an optional feature, part number PR0655-BAC, this feature can be activated at a later date if required.

A USB port also allows for a direct PC connection.

All relays have volt-free contacts and can be mixed between low and high voltage sources. Each controller or expansion requires a 24Vac or 24Vdc supply (a 2A PSU is available from RDM: - PR0625).

Intuitive / Plant Controller Descriptions	Part Number
Intuitive Superpack Controller (No Internal Display)	PR0650-SUP
Intuitive Superpack Controller (Internal Display)	PR0650D-SUP
Intuitive Superpack Controller (No Internal Display) and one solid state relay (for digital scroll)	PR0650-SUP-E1
Intuitive Superpack Controller (No Internal Display) and two solid state relays (for digital scroll)	PR0650-SUP-E2
Intuitive IO expansion board with 8 status inputs, 8 universal IOs and 12 relays	PR0661
Intuitive Mini IO expansion with 4 Universal Inputs and 5 relays.	PR0663

Configuration - Types

The controller has 8 configuration options:

Display value	Type	Control Type
1	Triple Pack	Fuzzy
2	Dual Pack and Condenser	Fuzzy
3	Pack and Dual Condenser	Fuzzy
4	Triple Condenser	Fuzzy
5	Triple Pack	Staged
6	Dual Pack and Condenser	Staged
7	Pack and Dual Condenser	Staged
8	Triple Condenser	Staged

The controller is delivered pre-configured as a Dual Pack and Condenser Controller (Type 2). See note on [changing type](#).



Please ensure all power is switched off before installing or maintaining this product.

Quick Start Guide (using a PC)

Controller menus and parameters as shown on the PC screen are shown in **bold** text.

- Select the **Service Menu** (the cogwheel icon at the bottom of the screen), enter service username and password (default user "install", password "1234"). Navigate to **Maintenance** and **Main Config** menu. Select the required control type, for example **FuzzPPC** sets sections 1 & 2 to pack (compressor) control and section 3 to condenser (fan) control using fuzzy logic control algorithm (as opposed to staged control). Set the number of sections required, probe type, number of Udev devices (current monitors) and the number of expansion boards being used. Select **Set Configuration** to save settings.
- Select the **Service Menu, Hardware, MainBrd 1** then **Set Parameters**. The **Set Parameters** menu will appear - this allows the hardware configuration for the main board to be set.
 - Set **M01 Uni1** to **Uni8** as required, for example if the first two universal inputs are 4-20mA pressure transducers and the third is a 0-10Vdc output to drive an inverter then **M01 Uni1** and **M01 Uni2** will be set to **4-20mA_I** and **M01 Uni3** will be set to **0-10v_O**.
 - Set **M01 Status Inp** as required, **0v** sets the status inputs to volt free contacts and **24vAc** sets them to require a 24vAC signal to switch on.
 - If a solid state relay (SSR) is fitted (to drive a digital scroll compressor) then **M01 Inv/Ssr Rly1** and/or **Rly2** need to be set to **SSR**.
- If using expansion boards then **ExtBrd 1** to **ExtBrd 10** should be set in a similar manner to **MainBrd**.
- Select the **Service Menu, Control, Section 1** then **Set Parameters**, if section 1 is set to pack (compressor) control then the basic parameters that need to be set are as follows:
 - **S01 Span 1** and **S01 Offset 1** set to match the pressure transducer, for example if the transducer is -1 to 14 Bar then the span is set to 15 Bar and the offset to -1.
 - Set **S01 Day Trgt** to the required target pressure.
 - If a variable speed inverter drive or a digital scroll compressor is being used then **S01 Inv** should be set to on.
 - If a digital scroll compressor is being used then **S01 Pwm** should be set to on.
 - Compressor stages now need to be set up (**S01 Stage 1** to **S01 stage 16**), for example, if 8 single stage compressors are being used then **S01 Stage 1** to **S01 stage 8** should all be set to **Comp**, **S01 Stage 9** to **S01 Stage 16** should be left as **None**. If a compressor has loaders then the main compressor body should be set to **Comp** and the loaders set to **Loader**. If a variable speed (inverter) compressor is being used then the stage should be set to **Inv** as an inverter run signal. If a digital scroll compressor is being used then **S01 Stage 1** should be set as **SSR** and **S01 Stage 2** set to **Inv**.
- If **Section 2** is also set to pack (compressor) control then all **S02** parameters should be set up in a similar way to **Section 1 (S01)**.
- If **Section 3** is set to Condenser (fan) control the **S03** should be set up as follows:
 - Select **Control, Section 3** then **Set Parameters**, set **S03 Span 1** and **S03 Offset 1** to match the pressure transducer being used.
 - Set **S03Day Trgt** to the target setpoint required.
 - If variable speed fans are being used then **S03 Inv** should be set to **On** and **S03 Stage 1** should be set to **INV** as an inverter enable signal.
- All three sections are now set up - if a section is not required then the transducer span for that section should be set to 0. As the sections are set up, the inputs and outputs are **not automatically mapped** to the physical inputs and outputs of the hardware (relays for example), this needs to be done manually. Although this makes the setup more complicated it does mean that a pack section, for example, can use all the IO on the main controller and the condenser section can use all the IO on an expansion board allowing the boards to be located in different locations (up to 500m apart) via the CANbus network.
- Select the **Service Menu, Mapping, IO Map 1** then **Set Parameters**. Each section can use up to 3 pressure transducers for monitoring but normally just use one for control, in this case **IO01 PressPos1** would be mapped to **Main Board Position 1** and **IO01 PressPos2** and **IOPressPos3** set to unused. Temperature probes 1-8, status inputs 1-16, Inverter position and relay positions 1 to 24 are mapped in a similar way.
- Sections 2 & 3 should now be mapped in a similar way to section 1 using **IO Map 2** and **IO Map 3**. If these sections are using the same main board as section 1 then the mapping would continue from where **IO Map 1** left off. For example, if section 1 has 4 compressors mapped to main board relay positions 1 to 4 then section 2 would start at main board relay position 5. If section 2 is using its own expansion board then **IO Map 2** would start at **Board 1 (not main) position 1** and so on using up the available IO on expansion board 1. If section 3 is also using its own board then **IO Map 3** would start at **Board 2 position 1** and so on. Two stage outputs cannot be mapped to the same relay position (section 1 alarm and section 2 alarm for example) but two status inputs can be mapped to the same physical input (section 1 standby and section 2 standby for example).


These are the minimum settings required to enable the controller to start operating, other parameters such as run proofs, status inputs, alarm settings and night setback can now be set as required.



Please ensure all power is switched off before installing or maintaining this product.

Front Display Panel

Remote Display (PR0620)



Left Hand Display

- The 4 character display shows the pressure (suction for pack, discharge for condensers). It scrolls through all sections.
- In set-up mode, displays the set-up menu items.
- In quick view mode, indicates the target pressure.
- In Override mode, indicates and allows the relays to be forced on.

Right Hand Display

- The 4 character display shows the section number of the pressure being displayed in left hand display "SEC 1", "SEC 2" etc.
- In set-up mode, display is blank.
- In Override mode, display is blank.


Front Panel Remote Display Buttons

Enter Button	Used along with down button to enter menu items.
Up Button	Used to scroll up.
Down Button	Used to scroll down.
Quick View Button	Used to view the target pressures (See Quick view section).
Override Button	Used with the "Enter" button, to go into the override mode or to view current variable output values (See Override section).
Info Button	Used to view the current alarms. (See Info section).



Please ensure all power is switched off before installing or maintaining this product.

Touch XL



The TouchXL when connected to the Superpack, is used as a display, mimicking the view of the standard web interface to the controller. It is used to interact with the application software and alarm indication.

As default, the TouchXL will show an overview list of current values such as pressures, temperatures and fault inputs. An optional graphical layout can be loaded onto the Superpack controller which will appear on the TouchXL. Layouts can be generated using the RDM Layout Editor software which is available separately.

The TouchXL has the benefit of being able to connect to the Intuitive device via USB (USB host 1 or 2) to micro USB or standard Ethernet connections over IP.

When connecting using the USB method, the communication of the two devices is automatic and the Touch XL will automatically configure itself for use.

Connecting over Ethernet comms requires the configuration of the TouchXL to be setup to 'look at' the Intuitive Superpack device. This can be carried out in the 'Network Configuration' page within the TouchXL service menus (only accessible directly on the touch screen). Please consult the specific documentation for more details.


Note: The TouchXL display is only compatible with Intuitive Superpack software V3.3 and above.




Please ensure all power is switched off before installing or maintaining this product.

Intuitive Plant Controller I/O Connections

Bottom Row Connections




Top Row Connections



Please ensure all power is switched off before installing or maintaining this product.

Mini I/O Connections

Bottom Row Connections



Top Row Connections



Universal Analogue Input / Output Connections

	0 or 4 -20mA or 0 – 10V Input
U1-U8 ●	0 or 4-20mA loop input or variable dc voltage ground.
U1-U8 ○	12v transducer feed or variable dc voltage input.

Inputs & Outputs

All Types	Description	Comments
Status Inputs 1-12 (Main) or 1 – 8 (Expansion)	0V return or 24 Vac	See Note 1 below
Analogue Inputs 1-8	Probe input	See Note 2 below
Universal IO 1-8 Universal Input Only 1-4 on Mini IO Expansion	Analogue Input/ Output	4-20mA, 0-10V, 0-5V, 0.5-4.5V, 0.5-9.5V, 1-2V, or 1-6V Input. 4-20mA, 0-20mA, 0-10V, 0-5V or 1-5V output (factory default is 0-10V In) (Inputs only on Mini IO Expansion)
Relay 1-12 Relay 1-5 (On Mini IO Expansion)	N/O, N/C and Common	Volt Free. If SSR is fitted then only the Common and N/C are connected
Status LED	Healthy LED	When powered up the LED will flash off/on every 0.5 seconds

Note 1: 24 Vac must have the same 24 Vac return as the supply voltage. If using the Plant controller 24V power supply only the 24Vac signal from the supply is required for the status input.

Note 2: Several probe types are available, see [Probe Type](#).



Please ensure all power is switched off before installing or maintaining this product.

Setting up the controller

Set-up access to the controller can be achieved several ways

- Through the front mounted buttons on the remote display or Touch display
- Direct access by PC via a USB or Ethernet connection
- Through the RDM Data Manager.*

*Note: Due to the high number of data points within the Superpack controller it is not advisable to network the controller to a Data Manager with firmware V2.0.8 or earlier. Doing so will not affect the operation of the Superpack controller but it will have an adverse effect on the Data Managers operation and therefore a Data Manager Firmware update is required.

Recommended set-up method

Due to the number of parameters available, it is recommended that this controller is set-up using a direct connection to a PC See [Setup via a PC](#). If you are not connecting to a network and want to set up the controller through the buttons, below is the structure within the display's menus.

Set-up through front buttons

To enter set-up mode, hold the Enter and Down buttons together for approximately 3 seconds until the message "Ent" appears on the display. Now press the Enter button again to enter the function menu, dEtY will be displayed. Scroll up or down to go through the list. Alternatively use either a PC connection for configurations or load a configuration from a memory-stick.

Set-up Menus

LH Display	LH Display	LH Display	LH Display	Option	Explained in Paragraph
dEtY	→ If Selected				
	d-0x (d-01 to d-06) x = Device Number	→ If selected		Select Device to view/change	Device Number
		dS0x (dS01 0o dS03) x = Section Number	→ If selected	Select Section to view/change	Section Number
			IO	View Input/ Output States	View Input/ Output States
			PARA	Set/view Parameters	Set/view parameters
	← ESC	← ESC	← ESC	Exit Menu	
Unit				Set/View Probe Type & Units	Set/View Probe Type & Units
Pres				Set/View Pressure Units	Set/View Pressure Unit
TyPE				Set/View Controller Type	Set/view device type
nSEC				Set/View Number of Sections	Set/view Sections
nUdS				Set/View Number of Current Monitors (Udev)	Set/view Udev Devices
nEbd				Set/View Number of Expansion Boards	Set/view number of Expansion Boards
rtc				Set/view Clock (rtc = Real Time Clock)	Real Time Clock
nEt				Set/view network configuration	Network Configuration
bCSt				Broadcast (Pressures)	Broadcast
SoFt				View software version	
USb				Save/Load onto USB device	USB Operation
Scrn				Viewed on mini touch display	Touch Display Screens
ESC				Exit set-up mode	




Please ensure all power is switched off before installing or maintaining this product.

Display (PR0620) Menu Structure

Hold the Enter and Down keys for 3 seconds then press Enter

Text, as it appears on the display, is shown in green.
Parameter description is shown in blue.



Device Selection

There are 6 devices that can be viewed / set up in the dEty menus.


- | | |
|-------------------------------|---|
| d-01 (Section) | Sections 1, 2 & 3, view I/O and set parameters (dS01 to dS03) |
| d-02 (U Dev) | Current Transformers 1 – 10, view I/O and set parameters (dS01 to dS10) |
| d-03 (IO Mapping) | Sections 1, 2 & 3, view I/O and set parameters (dS01 to dS03) |
| d-04 (Main Board) | For Main Board configuration, view I/O and set parameters (dS01) |
| d-05 (Expansion Board) | Expansion boards 1 – 10, view I/O and set parameters (dS01 to dS10) |
| d-06 (Stats) | Sections 1, 2 and 3 Outputs and set parameters (dS01 to dS03) |




Please ensure all power is switched off before installing or maintaining this product.

Main Menu Overview (PC Connection)

All available options are shown below. By default the Udev and ExBrd sections will be set to unused and will not show on the main menu. For setup via the PC connection, please see [Setup via a PC](#).



Please ensure all power is switched off before installing or maintaining this product.



Please ensure all power is switched off before installing or maintaining this product.

For setup using the display, we recommend using the following section order;

Set/ View Probe Types & Units

This operation is only available at the controller display or via a PC connection to the Plant controller. It cannot be set remotely via the Data manager front end system. Probe type changes apply to all probes on a controller and cannot be set individually to different types.

This option allows the user to set the probe types and units.

Unit Number	Probe Type	Units	Unit Number	Probe Type	Units
0	Probes not used	°C	12	NTC2K25	°F
1	PT1000	°C	13	NTC100K	°C
2	PT1000	°F	14	NTC100K	°F
3	NTC2K	°C	15	NTC5K	°C
4	NTC2K	°F	16	NTC5K	°F
5	NTC470R	°C	17	NTC6K	°C
6	NTC470R	°F	18	NTC6K	°F
7	NTC700R	°C	19	NTC10K	°C
8	NTC700R	°F	20	NTC10K	°F
9	NTC3K	°C	21	NTC10K (2)	°C
10	NTC3K	°F	22	NTC10K (2)	°F
11	NTC2K25	°C			

Temperature probe range -60 degrees Celsius to +128 degrees Celsius.

Set/ View Pressure Units

This operation is only available at the controller display or via a PC connection to the Plant controller. It cannot be set remotely via the Data manager front end system. This allows the pressure units to be set to Bar or Psi.

Type. Set/ View controller type

1. From the function menu scroll to "type", press enter
2. Use the up/down buttons to scroll through the type values. (See [configuration](#) on page 4)
3. Press enter.

The controller will reset with the selected type now programmed.

Note: When changing controller types from one type to another always check the parameters and the controller configuration to ensure they are appropriate for the application selected.

Set/ View Number of Sections

This allows the number of sections being used (1 to 3) to be set. For example, if the controller is being used to control a single suction section and single discharge section then only two sections need to be used, the third section will not be shown which will reduce the amount of unnecessary information displayed.

Set/ View Number of Udev Devices

This allows the number of Udev devices (USB current monitors) being used (1 to 10) to be set. As default (factory) setting this is set to 0 which will reduce the amount of unnecessary information displayed.

View Number of Expansion Boards

This allows the number of expansion boards being used (1 to 10) to be set. As default (factory) setting this is set to 0 and will reduce the amount of unnecessary information displayed.



Please ensure all power is switched off before installing or maintaining this product.

rtc. Real time clock

(This will automatically synchronise on network systems)

1. Use the up or down buttons to scroll through the display until the display reads "rtc"
2. Press enter. The display will show "t-1". Press enter again
3. Scroll hours up or down (0 – 23) press enter
4. Use up button to select "t-2", press enter
5. Scroll minutes up or down (0 – 59) press enter
6. Repeat for t-3 (seconds 0 – 59)
7. Repeat for t-4 (Days up to 31)
8. Repeat for t-5 (months up to 12)
9. Repeat for t-6 (Year up to 99)

Use up button to display "ESC", press enter to display "rtc"
Time clock is now set

IP Network Configuration

There are two network connection options

- IP-L (Rotary switches set to "000")
- IP-r (Rotary switches set to "xxx" where x is a number between 0 and 9)

IP-L allows a static IP address to be assigned to the controller, which would be used to connect the device onto a customer's local area network. This would allow the customer to view each controller using an internet browser.

IP-r (more commonly used) allows the device to be automatically assigned an IP address from a DHCP server running on the same network (e.g. a DMTouch). It uses the rotary switch address as a unique Network ID.

IP-L

To configure the Plant Controller for IP-L, set all three rotary switches to zero. The unit should then be connected to the network.

1. nEt. From the function menu you can now select nEt
 - Press enter and the display will show "IP-L", press enter
 - You can now set the address using the table below

Display	Option
IP-1	IP Address byte 1
IP-2	IP Address byte 2
IP-3	IP Address byte 3
IP-4	IP Address byte 4
nL	<u>Network Mask</u> Length
gt-1	Gateway Address byte 1
gt-2	Gateway Address byte 2
gt-3	Gateway Address byte 3
gt-4	Gateway Address byte 4
ESC	Exit network menu. Note: this option must be selected to save any changes made in this menu

Network Mask Length

To ease setup, a single network mask length value is used. If the address has been specified with a network mask value in dotted IP format e.g. 255.255.255.0 then the table below gives the conversion:

Mask	Length	Mask	Length	Mask	Length
255.255.255.252	30	255.255.254.0	23	255.254.0.0	15
255.255.255.248	29	255.255.252.0	22	255.252.0.0	14
255.255.255.240	28	255.255.248.0	21	255.248.0.0	13
255.255.255.224	27	255.255.240.0	20	255.240.0.0	12
255.255.255.192	26	255.255.224.0	19	255.224.0.0	11
255.255.255.128	25	255.255.192.0	18	255.192.0.0	10
255.255.255.0	24	255.255.128.0	17	255.128.0.0	09
		255.255.0.0	16	255.0.0.0	08



Please ensure all power is switched off before installing or maintaining this product.

IP-r

To configure the device for IP-r, set the three rotary switches to give each controller a unique identifier (other than 000). Connect the IP network via the Ethernet port. The Data Manager (or 3rd party server) will use DHCP to allocate the controller an IP address.

- From the function menu select nEt.
- Press enter and the display will show "IP-r", press enter.
- You can now view the address given by the DHCP server.

IP1: Shows the first IP address value	(10 in the example below)
IP2: Shows the second IP address value	(1 in the example below)
IP3: Shows the third IP address value	(2 in the example below)
IP4: Shows the forth IP address value	(86 in the example below)

Example: 10.1.2.86

Broadcast

0 = No broadcast. 1 = Broadcast Pressures. 2 = Broadcast CO2 Load Cycling

Set for 1. Broadcasts Pressure.

This allows pressure readings on the variable analogue Inputs to be broadcast over a Data Manager IP network for use with a Mercury Switch or Mercury IP Module. This remote pressure is used by the Mercury Switch or IP Module to calculate the Evaporator temperature.

Set for 2. Broadcasts CO2 commands

Allows the pack controller to send commands to the Data Manager which in turns sends "CO2 Case Off" commands to any cases set up on system to do CO2 load shedding

Note: See CO2 Load shedding documentation and RDM Data Manager User guide for further information on CO2 Load Shedding.

USB Operation

The following operations can be performed using a memory-stick plugged into the USB port: -

1. Export event log U-01
2. Export logged data U-02
3. Save configuration U-03
4. Load configuration U-04
5. Upgrade the software U-05

The above requires the user to enter the USB menu via the display and press enter at the appropriate display option.

For example to save the current configuration insert a USB Memory stick into one of the USB Host ports, go to the USB software menu option, press enter, then use the up key to scroll to U-03. Now press enter, the screen will flash "USB" until the operation has completed.

The file is transferred to the memory-stick in .zip format. The USB memory stick must be formatted as FAT32.



Please ensure all power is switched off before installing or maintaining this product.

PArA. Set/view parameters

1. From the function menu, scroll to dEty (device).
2. Select d01 (sections).
3. Select between ds01 (section 1), ds02 (section 2) or ds03 (section 3)
4. Scrolling to Para and pressing the enter key will show the first parameter (P-01). See: [Set up Menus](#) and subsequent parameter sections.

Section 1, 2, 3 Parameter table (d-01/ Sections)

Not all parameters apply to all controller types, for example P-71 is night setback for condenser fans so will not appear on a controller if it is set up as a pack (compressor) controller. In the right hand columns, the controller type will be shown, if that parameter applies to that type, if it does not apply it will be greyed out.

Note: All sections 1, 2, and 3 have the same parameter numbers

No.	Section Parameters	Range	Step	Units	Default			
					All Pack Fuzzy Default Settings	All Pack Staged Default Settings	All Condenser Fuzzy Default Settings	All Condenser Staged Default Settings
P-01	Span 1 *	-3.4 - 180	0.1	Bar	13.8	13.8	34.4	34.4
P-02	Span 2 *	-3.4 - 180	0.1	Bar	13.8	13.8	34.4	34.4
P-03	Span 3 *	-3.4 - 180	0.1	Bar	13.8	13.8	34.4	34.4
P-05	Offset 1	-3.4 - 180	0.1	Bar	0.0	0.0	0.0	0.0
P-06	Offset 2	-3.4 - 180	0.1	Bar	0.0	0.0	0.0	0.0
P-07	Offset 3	-3.4 - 180	0.1	Bar	0.0	0.0	0.0	0.0
P-09	Day Target Pressure	-3.4 - 180	0.1	Bar	2.1	2.1	12.7	12.7
P-10	Night Target Pressure	-3.4 - 180	0.1	Bar	2.1	2.1	12.7	12.7
P-11	Target Pressure Above P-9/10	-3.4 - 180	0.1	Bar	0.5	0.5	0.5	0.5
P-12	Target Pressure Below P-9/10	-3.4 - 180	0.1	Bar	0.5	0.5	0.5	0.5
P-13	Ext. Target Pressure	-3.4 - 180	0.1	Bar	3.1	3.1	14.7	14.7
P-15	Optimise Limit	-3.4 - 150	0.1	Bar	2.0	2.0		
P-16	Response On Speed	1 - 60	1	---	5	5	5	5
P-17	Response Off Speed	1 - 60	1	---	5	5	5	5
P-18	Fuzzy Weight	1 - 10	1	---	1		1	
P-22	Inverter Starts Per Hour	0 - 60	1	---	0	0		
P-23	Starts per Hour	0 - 60	1	---				
P-24	Run Smallest	0 = Off, 1 = On	1	-	0			
P-25	Always Run Last	0 = Off, 1 = On	1	-	0	0		
P-26	Comp Unload	0 = Off, 1 = On	1	-	0			
P-27	Equal Run	0 = Off, 1 = On	1	-	0			
P-28	Run Proof	0 = Off, 1 = On	1	-	0	0		
P-29	Gas Dump	0 = Off, 1 = On	1	-	0	0		
P-30	Gas Diff	-3.4 - 150	0.1	Bar	0.5	0		
P-31	Inverter	0 = Off, 1 = On	1	-	0	0	0	0
P-32	INV Bypass	0 = Disabled 1 = 1 + no retry 2 = 1 + 1 retry 3 = 1 + 2 retries 4 = 1 + 3 retries 5 = 1 + 4 retries	1	-	0	0	0	0
P-33	INV Minimum	0 - 100	1	%	0	0	0	0
P-34	INV Maximum	0 - 100	1	%	100	100	100	100
P-35	PWM Control	0 = Off, 1 = On	1	-	0	0		



Please ensure all power is switched off before installing or maintaining this product.

P-36	PWM Cycle Time	00:10 – 00:30	00:01	min:sec	00:20	00:20		
P-39	Fan Interlock	0 = Off 1 = On	1	---			0	0
P-40	Number of Stages	0 – 20	1	-		0		0
P-41	Stage On Delay	00:00 – 60:00	00:01	min:sec		00:10		00:10
P-42	Stage Off Delay	00:00 – 99:00	00:01	min:sec		00:10		00:10
P-50	Alarm Delay	00:00 – 99:00	01:00	min:sec	05:00	05:00	05:00	05:00
P-51	HP Alarm	-3.4 - 180	0.1	Bar	4.1	4.1	17.9	17.9
P-52	LP Alarm	-3.4 - 180	0.1	Bar	0.6	0.6	6.8	6.8
P-53	LP Shut-down	-3.4 - 180	0.1	Bar	0.4	0.4	6.2	6.2
P-54	Low Alarm Delay	00:00 – 99:00	01:00	min:sec	00:00	00:00	00:00	00:00
P-55	Fail	0 = Off, 1 = On	1	-	0	0	0	0
P-60	Liquid Level	0 = Off, 1 = On	1	-	0	0		
P-61	High Liquid Level	0 – 100	1	%	80	80		
P-62	Low Liquid Level	0 – 100	1	%	20	20		
P-63	Liquid Level Alarm Delay	00:00 – 99:00	01:00	min:sec	05:00	05:00		
P-70	Sticky Fans	0 – 16	1	---			0	0
P-71	Night Set Back	0 = Off, 1 = On 2 = Local, 3 = Remote	1	---			0	0
P-72	Night Reduction	0 – 100	1	%			30	30
P-73	Night Set On Time	00:00 – 23:59	00:01	min:sec	20:00	20:00	20:00	20:00
P-74	Night Set Off Time	00:00 – 23:59	00:01	min:sec	08:00	08:00	08:00	08:00
P-75	Night Pressure Limit	-3.4 - 180	0.1	Bar			25.0	25.0
P-76	Day Reduction	0 – 100	1	%			0	0
P-77	Day Pressure Limit	-3.4 - 180	0.1	Bar			25.0	25.0
P-78	Transducer fail Level	0 – 100	1	%			45	45
P-80	Control Type	0 = Fixed, 1 = Floating, 2 = Drop Leg, 3 = Float/ Drop Leg	1	---			0	0
P-81	Float Select	0 = Probe 1, 1 = Probe 2 2 = Probe 3, 3 = Probe 4 4 = Probe 5, 5 = Probe 6 6 = Probe 7, 7 = Probe 8 8 = Remote	1	---			0	0
P-79	Drop Leg Select	0 = Probe 1, 1 = Probe 2 2 = Probe 3, 3 = Probe 4 4 = Probe 5, 5 = Probe 6 6 = Probe 7, 7 = Probe 8 8 = Remote	1	---			0	0
P-82	Refrigerant	0 - 29 See: Refrigerant Table	1	---			0	0
P-83	Pressure Type	0 = Absolute, 1 = Gauge	1	---			1	1
P-84	Low Limit	-3.4 - 180	0.1	Bar			8.2	8.2
P-85	High Limit	-3.4 - 180	0.1	Bar			23.0	23.0
P-86	Condenser offset	0 – 20	0.1	°C			6.0	6.0
P-87	Discharge Trip	-3.4 - 180	0.1	Bar			16.0	16.0
P-88	Discharge Stop	-3.4 - 180	0.1	Bar			18.0	18.0
P-89	Discharge Offset	-3.4 - 180	0.1	Bar			2.0	2.0
P-64	Discharge Temperature	0 = Off, 1 = Probe 1 2 = Probe 2, 3 = Probe 3 4 = Probe 4, 5 = Probe 5 6 = Probe 6, 7 = Probe 7 8 = Probe 8	1	---			0	0
P-65	Discharge Trip Temperature	-60 – 256	0.1	°C			85	85
P-66	Discharge Stop Temperature	-60 – 256	0.1	°C			90	90



Please ensure all power is switched off before installing or maintaining this product.

P-67	Discharge Temperature Differential	-60 - 256	0.1	°C			10	10
P-90	Do Discharge Trip	0 = Off, 1 = Sect 2 2 = Sect 3	1	---	0	0		
P-91	Do Split	0 = Off, 1 = Mode 1, 2 = Mode 2, 3 = Mode 3, 4 = Mode 4	1	---			0	0
P-92	Split Temperature	-60.0 - 128.0	0.1	°C			7.2	7.2
P-93	Split Temperature Diff	0.0 - 10.0	0.1	°C			2.0	2.0
P-94	Sect 1 Split Press	-3.4 - 180	0.1	Bar			15.2	15.2
P-95	Split Press Diff	-3.4 - 180	0.1	Bar			1.4	1.4
P-96	Glide	-15 - 15	0.1	---			0.0	0.0
P-97	Ref Weight	0 - 100	1	%			0	0
P-98	Heat Reclaim	0 = Off, 1 = On,	1	---			0	0
P-99	TConst	0 - 10	1	---	1	1	1	1
P.600	Fan Reversal Select	0 = Off, 1 = On, 2 = local, 3 = remote	1	---			0	0
P-601	Fan Reversal Start Time	00:00 - 23:59	00:01	hrs:min			00:00	00:00
P-602	Fan Reversal Length	00:00 - 99:00	01:00	min:sec			00:00	00:00
P-603	Fan Reversal Delay	00:00 - 60:00	00:01	min:sec			00:00	00:00
P-604	Fan Reversal Fixed Speed on/off	0 = Off, 1 = On	1				1	1
P-605	Fan Reversal Fixed Speed	0 - 100	1	%			100	100
P-606	Fan Reverse Level	-3.4 - 180	0.1	Bar			7.0	7.0
P-100	Status Fault Delay	00:00 - 60:00	00:01	min:sec	00:10	00:10	00:10	00:10
P.101	General Fault Delay	00:00 - 60:00	00:01	min:sec	00:10	00:10	00:10	00:10
P-102	Standby Delay	00:00 - 60:00	00:01	min:sec	00:10	00:10	00:10	00:10
P.103	Status Fault 1	0 = Unused 1 = Comp N/O or Cond N/O 2 = Comp N/C or Cond N/C 3 = Gen N/O 4 = Gen N/C 5 = Standby N/O 6 = Standby N/C 7 = Run N/O or Heat N/O 8 = Run N/C or Heat N/C 9 = INV N/O 10 = INV N/C 11=Proof N/O 12=Proof N/C	1	---	0	0	0	0
P.118	Status Fault 16							
P.120	Stage 1	Pack Condenser 0 = None 0 = None 1 = Unused 1 = Unused 2 = Inv 2 = Inv 3 = Comp 3 = Fan 4 = Loader 5 = Trim 6 = SSR	1	---	0		0	
P.135	Stage 16							
P.140	Stage 1 size		0.1	---	0.0			
P.155	Stage 16 Size							
P.160	Stage 1 Relay 1		1	---		0		
P.175	Stage 1 Relay 16							



Please ensure all power is switched off before installing or maintaining this product.

P.180 ↓	Stage 2 Relay 1 ↓	0 = Off 1 = On	1	---		0		
P.195	Stage 2 Relay 16							
P.200 ↓	1 Stage 3 Relay 1 ↓	0 = Off 1 = On	1	---		0		
P.215	S1 Stage 3 Relay 16							
P.220 ↓	S1 Stage 4 Relay 1 ↓	0 = Off 1 = On	1	---		0		
P.235	S1 Stage 4 Relay 16							
P.240 ↓	S1 Stage 5 Relay 1 ↓	0 = Off 1 = On	1	---		0		
P.255	S1 Stage 5 Relay 16							
P.260 ↓	S1 Stage 6 Relay 1 ↓	0 = Off 1 = On	1	---		0		
P.275	S1 Stage 6 Relay 16							
P.280 ↓	S1 Stage 7 Relay 1 ↓	0 = Off 1 = On	1	---		0		
P.295	S1 Stage 7 Relay 16							
P.300 ↓	S1 Stage 8 Relay 1 ↓	0 = Off 1 = On	1	---		0		
P.315	S1 Stage 8 Relay 16							
P.320 ↓	S1 Stage 9 Relay 1 ↓	0 = Off 1 = On	1	---		0		
P.335	S1 Stage 9 Relay 16							
P.340 ↓	S1 Stage 10 Relay 1 ↓	0 = Off 1 = On	1	---		0		
P.355	S1 Stage 10 Relay 16							
P.360 ↓	S1 Stage 11 Relay 1 ↓	0 = Off 1 = On	1	---		0		
P.375	S1 Stage 11 Relay 16							
P.380 ↓	S1 Stage 12 Relay 1 ↓	0 = Off 1 = On	1	---		0		
P.395	S1 Stage 12 Relay 16							
P.400 ↓	S1 Stage 13 Relay 1 ↓	0 = Off 1 = On	1	---		0		
P.415	S1 Stage 13 Relay 16							



Please ensure all power is switched off before installing or maintaining this product.

P.420 ↓	S1 Stage 14 Relay 1 ↓	0 = Off 1 = On	1	---		0		
P.435	S1 Stage 14 Relay 16							
P.440 ↓	S1 Stage 15 Relay 1 ↓	0 = Off 1 = On	1	---		0		
P.455	S1 Stage 15 Relay 16							
P.460 ↓	S1 Stage 16 Relay 1 ↓	0 = Off 1 = On	1	---		0		
P.475	S1 Stage 16 Relay 16							
dFLt	Restore Default Settings (Panel Mount Display Only)							

Refrigerant Table

No.	Gas	No.	Gas	No.	Gas	No.	Gas	No.	Gas
0	None	6	R401A	12	R407A	18	R507	24	R449A
1	R22	7	R401B	13	R407B	19	R717	25	R513A
2	R32	8	R401C	14	R407C	20	R290		
3	R134a	9	R402A	15	R500	21	R744		
4	R142B	10	R402B	16	R502	22	R407F		
5	R227	11	R404A	17	R503	23	R410A		

* Span and Offset allows for the full range of the transducer to be used by the controller.
 Span is the full range of the transducer
 Offset is the value below zero.
 Note. The controller uses absolute pressure; if gauge pressure is required, add +1 Bar to the offset value.

Example: Danfoss AKS 33 with range: -1 bar to 12 bar
 Span would be 190 (13 bar)
 Offset would be -15 (-1 bar)

If only transducer input 1 and/or 2 in use please see [note on the display](#).

Run smallest

Set to 'on' - When all compressors are off (because the target pressure has been satisfied) the controller, when the pressure rises, will always turn on the smallest compressor after the variable output has reached 100%. If the ASC timer is running for the smallest compressor, the controller will **NOT** bring on any other available compressors, the variable output will remain at 100% and the controller will wait until the ASC Timer has elapsed and then turn on the smallest.

Please note that this is true for **any** pressure condition.



Please ensure all power is switched off before installing or maintaining this product.

Current Transformer Parameters (d-02/ CT Monitor - UDev)

Note: All Current Transformers Interfaces 1 to 10 have the same parameter numbers

No.	Section Parameters	Range	Step	Units	Default
P-01 ↓ P-05	CT Range 1 ↓ CT Range 5	0 - 500	1	Amps	0
P-11 ↓ P-15	CT Position 1 ↓ CT Position 5	0 - 48	1	---	0
P-21 ↓ P-25	CT Low Amp 1 ↓ CT Low Amp 5	0 - 500	1	Amps	5
P-31 ↓ P-35	CT High Amp 1 ↓ CT High Amp 5	0 - 500	1	Amps	80
P-41 ↓ P-45	CT Alarm Delay 1 ↓ CT Alarm Delay 5	00:00 - 99:00	01:00	min:sec	05:00

Pressure, Probe, Status, Inverter and Relay Position Parameters (d-03/ Mapping - IOMap)

Controller inputs and outputs are not automatically allocated by the controller, these are manually allocated by the user and provides greater flexibility as to where the expansion modules (if used) are located. For example, if section 2 is set to use 4 compressors then these can be mapped to any relay position on any expansion board. Relays can also be mapped to the main controller if there are relays available which have not been mapped to section 1. The same applies to all other inputs and outputs such as pressure transducers and fault inputs.

All sections 1, 2 and 3 have the same parameter numbers.

The Range covers all possible positions including the maximum amount of expansion modules.

No.	Section Parameters	Range	Step	Units	Default
P-01 ↓ P-03	Pressure Position 1 ↓ Pressure Position 3	0 - 88	1	---	0
P-10 ↓ P-17	Probe Position 1 ↓ Probe Position 8	0 - 88	1	---	0
P-20 ↓ P-35	Status Position 1 ↓ Status Position 16	0 - 92	1	---	0
P-40	Inverter Position	0 - 88	1	---	0
P-50 ↓ P-73	Relay Position 1 ↓ Relay Position 24	0 - 132	1	---	0



Please ensure all power is switched off before installing or maintaining this product.

Universal I/O, Status Inputs, Invert Relays, Probe Offsets Configuration (d-04/ Hardware - Main Board)

No.	Section Parameters	Range	Step	Units	Default
P-01 ↓ ↓ ↓	Universal I/O 1 ↓ ↓	0 = 4-20mA Input 1 = 0-10V Input (Default) 2 = 0-5V Input 3 = 0.5-4.5V Input 4 = 0.5-9.5V Input 5 = 1-2V Input 6 = 1-6V Input 7 = 4-20mA Output 8 = 0-20mA Output 9 = 0-10V Output 10 = 0-5V Output 11 = 1-5V Output	1	---	1
P-10	Universal I/O 8				
P-10	Status Inputs	0V / 24V ac	1	---	0
P-20 ↓	Invert Relay 1 ↓	0 = Off 1 = On	1	---	0
P-31	Invert Relay 12				
P-40 ↓ ↓ ↓	Offset 1 ↓ ↓ ↓	-20 to +20	0.1	°C	0.0
P-47	Offset 8				

Universal I/O, Status Inputs, Invert Relays, Probe Offsets Configuration (d-05/ Hardware - Ext Board)

No.	Section Parameters	Range	Step	Units	Default
P-01	Board Type	0 = Unused 1 = IO 2 = Mini IO			
P-02 ↓ ↓ ↓	Universal I/O 1 ↓ ↓	0 = 4-20mA Input 1 = 0-10V Input (Default) 2 = 0-5V Input 3 = 0.5-4.5V Input 4 = 0.5-9.5V Input 5 = 1-2V Input 6 = 1-6V Input 7 = 4-20mA Output 8 = 0-20mA Output 9 = 0-10V Output 10 = 0-5V Output 11 = 1-5V Output	1	---	1
P-09	Universal I/O 8				
P-11	Status Inputs	0V / 24V ac	1	---	0
P-21 ↓	Invert Relay 1 ↓	0 = Off 1 = On	1	---	0
P-32	Invert Relay 12				
P-41 ↓ ↓ ↓	Offset 1 ↓ ↓ ↓	-20 to +20	0.1	°C	0.0
P-48	Offset 8				

Compressor Run Hours and Compressor Starts (d-06/ Stats)

Note: All sections 1, 2 and 3 have the same parameter number

No.	Section Parameters	Range	Step	Units	Default
P-01	Reset Stats	0 - 1	1	---	0



Please ensure all power is switched off before installing or maintaining this product.

Parameter Descriptions

Section Parameters Description (d-01/ Sections)

No.	Parameter	Description
P-01/02/03	Transducer 1/2/3 Span	Range of the transducers.
P-05/06/07	Transducer 1/2/3 Offset	Transducer value above or below zero.
P-09	Day Target Pressure	Pressure target, control will try to maintain this pressure during day time. See P-74
P-10	Night Target Pressure	Pressure target, control will try to maintain this pressure during night time. See P-73
P-11	Target Pressure Above P-09/10	Set-point above the target, used to obtain a "dead-band".
P-12	Target Pressure Below P-09/10	Set-point below the target, used to obtain a "dead-band".
P-13	External Target Pressure	Pressure target when Sect1/2/3 Run is off. Control will try to maintain this pressure until Sect1/2/3 Run is on. At this point P-09/10 used. See: Status Inputs
P-15	Optimise Limit	This is an offset that is added to the target pressure when using the Data Manager Energy feature Pack Optimisation. For example if target pressure is 2.1 Bar and Optimise Limit set to 0.5 Bar. The remote optimise command will only be able to optimise the current suction set point up to a maximum of 2.6 Bar.
P-16	Response On Speed	Allows the user to speed up/slow down the stage on speed (Option: - 1 to 60 with 60 being fastest response). Note: This parameter applies to the inverter output only when using any of the Staged types.
P-17	Response Off Speed	Allows the user to speed up/slow down the stage off speed (Option: - 1 to 60 with 60 being fastest response). Note: This parameter applies to the inverter output only when using any of the Staged types.
P-18	Fuzzy Weight	When using an inverter output this setting allows the output value to decrease or increase more quickly. If this is set to 1 (default) then the output will ramp between 100% and 0% before switching the next stage. If set to 10 and the pressure is far away from the setpoint then the inverter will ramp from a lower value (50% for example). This parameter should not normally need to be changed from default (1).
P-22	Inverter Starts Per Hour	Limits the inverter starts to this many starts per hour, set to 0 if not required.
P-23	Starts per hour	Limits a compressor to this many starts per hour, set to 0 if not required.
P-24	Run smallest	See explanation under the parameter tables for this parameter Run Smallest
P-25	Always run last	Keeps the last stage running except for a Low Shutdown condition. If the last stage is an inverter, the inverter enable will stay energised, but the inverter analogue output may well decrease to 0% if pressure is below the set-point.
P-26	Comp Unload	Selects the order the compressor loaders are switched off. See Compressor Loaders
P-27	Equal run Times	Equalises compressor run times. See Equal run Times
P-28	Run Proof	See section Run-Proof
P-29	Gas Dump	Enables Gas Dump feature. See Gas Dump
P-30	Gas Diff	Diff below the set point that the Gas Dump valve is opened. See Gas Dump
P-31	Inverter	Enables the inverter analogue output and associated relay.
P-32	Inv Bypass	Enable for Inverter Bypass feature. See INV Bypass
P-33	Inverter Min	The minimum percentage the inverter will operate to e.g. if set to 25% the inverter output will never go below this value. This should be set to 10% when using a digital scroll compressor.



Please ensure all power is switched off before installing or maintaining this product.

P-34	Inverter Max	The maximum percentage the inverter will operate to e.g. if set to 80% the inverter output will never go above this value
P-35	PWM Control	Pulse width modulation control, used to control a digital scroll compressor.
P-36	PWM Cycle Time	The total time for one on/off cycle.
P-39	Fan Interlock	When set to "On" the first condenser fan stage will switch on when any compressor is running. (Only applies if a fan stage is set to "fan", if stage is set to "inverter" the interlock will have no effect on that stage.)
P-40	Number of Stages	Number of stages in the system
P-41	Stage On Delay	Delay time between stages on (Staged types only)
P-42	Stage Off Delay	Delay time between stages off (Staged types only)
P-50	Alarm Delay	Delay before HP and LP alarms are signalled
P-51	HP Alarm	HP alarm set-point
P-52	LP Alarm	LP alarm set-point
P-53	LP Shut-down	LP shut-down set-point, all stages go off when this is reached
P-54	Low Alarm	Delay applied before LP Shutdown alarm is generated. Note as soon as the LP Shutdown set point is reached any Compressor/Condenser stages, for the associated section, still operating will go off immediately and does not wait for the LP Shutdown alarm to be created.
P-55	Fail	The following will occur in the event of pressure transducer fault: - If set to On then all Compressors or Fans will turn On in the event of a transducer failure. If set to Off then all Compressors or Fans will turn Off in the event of a transducer failure.
P-60	Liquid Level	Enable for Liquid Level feature. See Liquid Level
P-61	High Liquid Level	Settings at which High Liquid Level alarm is generated
P-62	Low Liquid Level	Settings at which Low Liquid Level alarm is generated
P-63	Liquid Level Alarm Delay	Delay applied before the Low or High liquid alarm is generated.
P-70	Sticky Fans	Sticky fans operation allows the user to turn the fans off in a way that keeps a number of fans running longer. See Sticky Fans
P-71	Night Set Back	Turns on the night set back level. Note This feature is intended to be used when all of the fans are controlled by the inverter. If fan relays are selected, they will never come on as the inverter is required to go to 100% before staging the next fan. There are 4 options : - Off - Night Feature is not used. Controller uses what is set in Day Reduction (P-76). On - Night Reduction (P-72) is always used. Local - Uses times in Night Set On and Night Set Off parameters (P-73) and (P-74) to determine Day / Night. Remote - Uses GP Timer to determine Day / Night.
P-72	Night Reduction	Reduces inverter output by this amount during night settings.
P-73	Night Set Back On Time	Time for the night set back feature to operate.
P-74	Night Set Back Off Time	Time for the night set back feature to go off.
P-75	Night Set Back Pressure Limit	Pressure set-point to disable the night set back feature. Night set back is disabled above this level and enabled below it.
P-76	Day Reduction	Reduces the inverter output by this amount when the timer is not in its night zone.
P-77	Day Pressure Limit	Pressure set-point to disable the day reduction feature. Day reduction is disabled above this level and enabled below it.
P-78	Transducer fail Level	Sets the output level of the inverter if the transducer fails.
P-80	Control Type	Selects between; Fixed, Floating Head, Drop Leg or Floating Head/ Drop leg for Condenser control only. Fixed - Uses the set-point parameter as its target (P-09/10) with the corresponding pressure transducer. Floating - Uses the temperature of a selected probe converted to a pressure as the set-point along with the corresponding pressure transducer. Drop Leg - Uses a temperature probe converted to a pressure. Float/ Drop Leg - Uses both Floating Head and Drop Leg control strategies.
P-81	Float Select	Selects the probe that measures the "floating" temperature. Note: This



Please ensure all power is switched off before installing or maintaining this product.

		would be fitted to the Air On of the Condenser. See Floating Head Pressure
P-79	Drop Leg Select	Selects the probe that measures the temperature which is converted to the corresponding pressure using the selected refrigerant. See Drop Leg Control
P-82	Refrigerant	Select the refrigerant used in the system. See Refrigerant Table
P-83	Pressure Type	Select whether Absolute pressure or Gauge pressure being used.
P-84	Low Limit	Stops the floating pressure target from going below this level.
P-85	High Limit	Stops the floating pressure target from going above this level.
P-86	Condenser offset	Used to set a condenser differential, which is added to the incoming temperature to produce a "floating" set-point.
P-87	Discharge Trip	If Discharge Pressure exceeds this setting, compressors will turn off gradually or Inverter will ramp down to try to reduce the discharge pressure before it reaches discharge stop parameter P-88.
P-88	Discharge Stop	If Discharge Pressure exceeds this setting All compressors on the assigned pack go off immediately and all fans come on immediately. A Discharge Trip Alarm is generated. Note: If using an Inverter on the Compressors the output to the Inverter will go to 0% immediately as well as all compressors going off. The controller will remain in the stop state for a minimum of 1 minute regardless of pressure.
P-89	Discharge Offset	Offset the discharge temperature by this value. This is the diff below P-87 & P-88 below which comps start staging in again.
P-64	Discharge Temperature	Allows a discharge temperature probe to be fitted to the condenser section which shuts down compressor(s) in the pack section(s) if the temperature goes too high. The "Do Discharge Trip" parameter (P-90) needs to be set in the associated pack section(s).
P-65	Discharge Trip Temperature	If this temperature is reached, the controller will start staging off compressors. Compressors will start staging back on once the temperature drops below the set point minus the differential (P-67) and a one minute delay has expired.
P-66	Discharge Stop Temperature	If this temperature is reached, the controller will stop the digital scroll compressor(s) on the pack section(s). The compressor(s) will start staging back on once the temperature drops below the set point minus the differential (P-67) and a one minute delay has expired.
P-67	Discharge Temperature Dif.	The value below the discharge trip (P-65) and discharge stop temperature (P-66) before the compressor(s) will restart, this is subject to a one minute delay.
P-90	Do Discharge Trip	Enable feature by selecting which condenser is used on this pack, this must be switched on if using a digital scroll compressor.
P-91	Do Split	Enables the Condenser Split feature and setting of modes 1 to 4. Mode 1: Condenser split relay only operates. Mode 2: All staged condenser fans switch off, and split relay operates. Mode 3: All even numbered staged fans switch off, and split relay operates. Mode 4: All odd numbered staged fans switch off, and split relay operates. The split condenser feature has no effect on the operation of the Inverter output (if used), this will operate as normal.
P-92	Split Temp	If outside ambient air temperature falls to this value then the condenser split relay will come on. Note the Condenser Float temperature probe is used as the air temperature reference.
P-93	Split Temp Diff	Diff above for the split temp feature. If outside ambient air temperature rises above Split Temp parameter plus Split Temp Diff parameter then the Condenser split relay will go off.
P-94	Split Pressure	If the discharge pressure rises above this setting then the condenser split relay will be forced off regardless of temperature.
P-95	Split Pressure Diff	Diff below parameter for Split Pressure feature. If the pressure falls below Split Pressure set point plus Split Pressure Diff parameter then the condenser split relay will return to normal operation.



Please ensure all power is switched off before installing or maintaining this product.

P-96	Glide	The glide value applied to the refrigerant (when using floating head pressure control)
P-97	Ref Weight	This is the weighting value applied to the refrigerant temperature to pressure look up tables (when using floating head pressure control). When set to 0% the calculated pressure is the liquid (bubble) value, when set to 100% the calculated pressure is the vapour (dew) value, when set to 50% it is half way between the liquid and vapour value.
P-98	Heat Reclaim	Enable for Heat Reclaim. See IO Mapping 0 = Off (Not Used) 1 = On (Uses Ext Set Point) 2 = On Rly(Uses Ext Set Point and allocates a Relay)
P-99	TConst	Time constant, this applies a damping effect to the pressure reading, the higher the value the higher the damping. This is used to filter out sudden jumps in pressure and should not normally be changed from the default value (1).
P-600	Fan Reversal Select (For use with variable speed fans only)	This feature allows a relay to be allocated as a fan reverse signal. This will reverse the condenser fans at a pre-set time for a pre-set period to assist clearing debris that may have accumulated in the fans. For relay mapping see IO mapping . When activated the assigned relay will activated for fan reverse length (P602). 0 = Off, feature not used 1 = On, allows fans to be forced manually into reverse 2 = Local, uses the controller's internal GP timer to switch the fans into reverse. 3 = Remote, uses the Data Manager's GP timer to switch the fans into reverse.
P-601	Fan Reversal Start Time	Set the local time of day when fans are switched into reverse (only applies if P-600 is set to local).
P-602	Fan Reversal Length	Sets the length of time fans will run in reverse.
P-603	Fan Reversal Delay	Sets a delay period between fans stopping and being switched into reverse.
P-604	Fan Reversal Fixed Speed on/off	If set to On, the fans will run in reverse at a fixed speed (set in P-605), if set to Off then the fans will run at their normal control speed.
P-605	Fan Reversal Fixed Speed	Sets the fixed reverse fan speed if P-604 set to On.
P-606	Fan Reverse Level	If the discharge pressure drops below this value then the fan reverse cycle will not operate, this is to prevent over condensing. If the pressure drops below this value during a fan reverse cycle then the cycle will be stopped and cannot be reinstated for a minimum of one hour.
P-100	Status fault Delay	Time delay before status faults are activated.
P-101	General Alarm Delay	Time delay before general faults are activated.
P-102	Standby Delay	Time delay between the standby input being activated and the controller going into standby.
P103 ↓ P118	Status Fault 1 ↓ Status Fault 16	Used to select the type of input required See: Status Inputs
P120 ↓ P135	Stage 1 ↓ Stage 16	Select the output device for this stage
P140 ↓ P155	Stage 1 Size ↓ Stage 16 Size	Sets the relative size for each compressor
P160 ↓ P475	Stage 1 Relay 1 to 16 ↓ Stage 12 Relay 1 to 16	Allocates compressor relays to stages (staged type only, not fuzzy)



Please ensure all power is switched off before installing or maintaining this product.

Current Transformer Parameters Description (d-02/ CT Monitor - UDev)

No.	Parameter	Description
P-01 ↓ P-05	CT Range 1 ↓ CT Range 5	Range of CT
P-11 ↓ P-15	CT Position 1 ↓ CT Position 5	What compressor CT is attached to 1 to 16 corresponds to Section 1 compressor relays 17 to 32 corresponds to Section 2 compressor relays 33 to 48 corresponds to Section 3 compressor relays
P-21 ↓ P-25	CT Low Amp 1 ↓ CT Low Amp 5	Low current alarm set point
P-31 ↓ P-35	CT High Amp 1 ↓ CT High Amp 5	High current alarm set point
P-41 ↓ P-45	CT Alarm Delay 1 ↓ CT Alarm Delay 5	Alarm delay for low and high current alarms

Pressure, Probe, Status, Inverter and Relay Position Parameters Description (d-03/ Mapping - IOMap)

No.	Parameter	Description
P-01 ↓ P-03	Pressure Position 1 ↓ Pressure Position 3	Position of transducer inputs
P-10 ↓ P-17	Probe Position 1 ↓ Probe Position 8	Position of probe inputs
P-20 ↓ P-35	Status Position 1 ↓ Status Position 16	Position of status inputs
P-40	Inverter Position	Position of Inverter output
P-50 ↓ P-73	Relay Position 1 ↓ Relay Position 24	Position of relay outputs Relay Position 17 is reserved for a Condenser split Relay Relay Position 18 is reserved for a Heat Reclaim Relay Relay Position 19 is reserved for a Condenser / Fan Bypass Relay Relay Position 24 is reserved for an alarm relay

Universal I/O, Status Inputs, Invert Relays, Probe Offsets Configuration Description (d-04/ Hardware - Main Board)

No.	Parameter	Description
P-01 ↓ P-08	Universal I/O 1 ↓ Universal I/O 8	Select the type of universal input or output
P-10	Status Inputs	Select whether 0V return or 24V ac
P-20 ↓ P-31	Invert Relay 1 ↓ Invert Relay 12	Used to invert relay operation
P-40 ↓ P-47	Offset 1 ↓ Offset 8	Offset probes by this amount



Please ensure all power is switched off before installing or maintaining this product.

Universal I/O, Status Inputs, Invert Relays, Probe Offsets Configuration Description (d-05/ Hardware - Ext Board)

No.	Parameter	Description
P-01	Board Type	Select the type of expansion board being used
P-01 ↓ P-08	Universal I/O 1 ↓ Universal I/O 8	Select the type of universal input or output
P-10	Status Inputs	Select whether 0V return or 24V ac
P-20 ↓ P-31	Invert Relay 1 ↓ Invert Relay 12	Used to invert relay operation
P-40 ↓ P-47	Offset 1 ↓ Offset 8	Offset probes by this amount

Compressor Run Hours and Compressor Starts Description (d-06/ Stats)

No.	Parameter	Description
P-01	Reset Stats	Reset stats by changing from Reset 1 to Reset 2 or vice versa



Please ensure all power is switched off before installing or maintaining this product.

Using a Digital Scroll Compressor

A digital scroll compressor requires an Inverter relay allocated to it to switch on the compressor and a solid state relay (SSR) to energise the capacity solenoid. The SSR output is switched **off** to fully load the compressor and **on** to fully unload the compressor. The compressor is loaded and unloaded in 20 second cycles as default (P-36 cycle time) so if the compressor is required to run at 50% capacity then the SSR output will be on for 10 seconds and off for 10 seconds. Similarly if the compressor is required to run at 75% capacity the SSR will be off for 15 seconds and on for 5 seconds.

The following procedure is an example of how the controller should be set up to run a digital scroll compressor:

- When ordering, the controller must be specified with a solid state relay fitted in relay position 1 (PR0650-SUP-E1) or if two digital scrolls are being controlled then a solid state relay is required in relay positions 1 & 2 (PR0650-SUP-E2). Only one digital scroll compressor can be controlled on each compressor section.
- Under the Main Board set up page, set relay 1 to SSR and relay 2 to SSR if fitted.
- Under the section parameters set Inverter to **on** (P-31) and set inverter minimum to 10% (P-33) or refer to compressor manufacturer's specification for a minimum capacity (to provide compressor cooling).
- Set PWM Control to **on** (P-35) and set PWM Cycle time to 20 seconds (P-36) or refer to compressor manufacturer's specification.
- Set stage 1 to SSR and stage 2 to Inverter (P-120 & P-121).
- Under the stage IO map, map the SSR to the position the SSR is fitted on the controller (relay position 1 or 2) and the inverter relay to any other relay which is being used to switch the compressor on.
- The Discharge Stop and Trip parameters need to be set according to manufacturer's specification (P-64, P-65, P-66, P-87, P-88 and P-89), even if the condenser section is not being used, and the "Do Discharge Trip" parameter must be set to **on** (P-90). These parameters enable the digital scroll compressor to be stopped automatically if pressure and/or temperature limits are exceeded.
- If the controller is set to staged control (Types 5-8) then stage 1 should be set to relays 1 & 2 ON (SSR & INV). When there is a demand for the digital scroll to run the enable relay (INV) will switch on and the capacity solenoid (SSR) will be modulated on and off as required.

If using suction pressure optimisation as well as floating head pressure control, particular attention should be paid to the optimise limit parameter (P-15) and the float low limit parameter (P-84). These should be set so that it is not possible for the suction and discharge pressures to get too close to each other, typically a 5.2 Bar differential must be maintained, again refer to the compressor manufacturer's specification for the correct limits.

Liquid Level

Each pack section has the option of a liquid level input using a variable mA or dc voltage on a Universal Input on the Plant controller.

- An input of 0mA, 4mA or 0V will give a reading of 0%, and an input of 20mA, 5V or 10V will give a reading of 100%.
- When the liquid level parameter (P-60) is set to on, the controller will use the "S0x Press 2" input as the liquid level input, the transducer span and offset settings (Span 3 and Offset 3) will have no effect and can be left as default.
- If the liquid level parameter is set to off then this input will become the third pressure transducer input "S0x Press 2" (after Suction Press and Press 1) and the parameters Span 3 and Offset 3 can be set to match the pressure transducer.
- The parameters "Low Liquid Level Alarm" (P-62) and "High Liquid Level Alarm" (P-61) can be set if level alarms are required, the alarm has a settable delay (P-63).
- When mapping the liquid level input to one of the physical universal inputs (mA or voltage), the parameter "PressPos 3" is used.

Note: Each pack section has 3 pressure inputs available, by default these are named "Suction Press", "S0x Press 1" and "S0x Press 2". Only the Suction pressure input is used for control purposes, S0x Press 1 and S0x Press 2 are used for optional monitoring only. The parameters that relate to these three inputs are "Span 1", "Span 2", "Span 3", "Offset 1", "Offset 2" and "Offset 3". Care should be taken as, for example, "Span 3" applies to the input "Press 2".



Please ensure all power is switched off before installing or maintaining this product.

Run-Proof

This is a “global” parameter. If set to 'on', the Status fault inputs are used to prove that compressors are running.

- Configure the status inputs, using either Compressor Normally Closed or Compressor Normally Open, so that correspond with each relay output.
- When the relay output is energised and the run proof signal isn't returned within the specified time period, the compressor relay will go off and be taken out of the control strategy until the run proof has been reset.
- The run-proof feature uses the status fault delay (P.100) and all run proof signals must be returned within this delay period.
- Run proofs are used with compressor (Comp) stages only.
- This feature can be used in both Fuzzy and Staged applications.
- Example, when the status input is set to Compressor Normally Closed then the input must become open circuit for the compressor run to be confirmed and vice versa.

Note: If using “Run Proofs” and Compressor Loaders.

If you have a compressor with loaders you need to set up status inputs for the compressor body and the loaders and map the inputs accordingly. For example, if relay 1 is a compressor and relays 2 & 3 are the associated loaders then status inputs 1, 2 & 3 would be set as compressors, if inputs 1, 2 & 3 are then mapped to physical input 1 on the controller then when the compressor fault input is activated the associated loaders will be switched off as well as the compressor body.

Run proof inputs must not be used on Inverter (variable speed) stages. If an Inverter is being used that is required to be stopped in the event of a run proof signal not being returned then the stage should be set to “Inv” the fault input set to “Inv N/O” or “Inv N/C” and the Inverter bypass parameters set up as required. See “[Inverter Bypass](#)” section

Resetting a Run Proof

To reset the run proof for any stage, after maintenance, and return a compressor back into the control strategy, the proof status input should be activated momentarily. If a proof status input is not set up then resetting the controller will have the same effect.

Gas Dump

Enabled by setting 'Gas Dump Enable' (P-29) to 'on'.

Fuzzy Logic

In Fuzzy pack control the Gas dump relay will come on when the Suction Pressure drops below the Set Point (P-09/10) plus the Gas Diff (P-30) and all but the last compressor has turned off.

When an Inverter output is configured using Fuzzy pack control, the Gas dump relay will come on only when the Inverter is active, i.e. above 0% and all other Compressors configured in that section are off.

Staged Logic

With Staged pack control, the Gas Dump relay will come on only when last compressor is running. The Gas dump relay will go off again when either:

The pressure rises above the Set Point (P-09/10)

Or

When the last stage compressor goes off, or Inverter Enable is turned off.



Please ensure all power is switched off before installing or maintaining this product.

Compressor Loaders

Parameter 'Comp Unload' (P-26) determines the order the compressor loaders are switched off, providing the option to turn off one compressor and its loaders before turning off the next or to switch off all the loaders first leaving compressors running unloaded.

If (P-26) is set for 0 (Off) then the compressor loaders and compressor body will be switched off before another loader is switched off.

If (P-26) is set for 1 (On) then all loaders will be switched off before a compressor body will be switched off leaving any compressors running unloaded before switching a compressor body off.

Example 1 (Type 1 Fuzzy)

Pack set up: 2 compressors with 2 Loaders each.

Sect 1 stage 1 = Comp.
Sect 1 stage 4 = Comp.

Sect 1 stage 2 = Loader.
Sect 1 stage 5 = Loader.

Sect 1 stage 3 = Loader.
Sect 1 stage 6 = Loader.

Parameter (P-26) = 0 (Off)

Switching On sequence: Pressure above set point + diff

First compressor comes on. Compressor loader 1 comes on. Compressor loader 2 comes on.

Second compressor comes on. Compressor loader 1 comes on. Compressor loader 2 comes on.

Switching Off sequence: Pressure below set point – diff

One compressor loader 2 goes off. Compressor loader 1 goes off. Compressor body goes off.

Next compressor loader 2 goes off. Compressor loader 1 goes off. Compressor body goes off.

This configuration switches off one compressor and its loaders before switching off the next compressor loader. Thus leaving one compressor fully loaded till first one is completely off.

Example 2 (Type 1 Fuzzy)

Pack set up: 2 compressors with 2 Loaders each.

Sect 1 stage 1 = Comp.
Sect 1 stage 4 = Comp.

Sect 1 stage 2 = Loader.
Sect 1 stage 5 = Loader.

Sect 1 stage 3 = Loader.
Sect 1 stage 6 = Loader.

Parameter (P-26) = 1 (On)

Switching On sequence: Pressure above set point + diff

First compressor comes on. First compressor loader 1 comes on. First compressor loader 2 comes on.

Second compressor comes on. Second compressor loader 1 comes on. Second compressor loader 2 comes on.

Switching Off sequence: Pressure below set point – diff

One compressor loader 2 goes off. Compressor loader 1 goes off.

Next compressor loader 2 goes off. Compressor loader 1 goes off.

One compressor body goes off. Next compressor goes off.

This configuration switches off all loaders before switching off a compressor, thus leaving both compressors running unloaded before switching one completely off.

Note: If using an Inverter with loaders, The Inverter and its loader/s will always be the last to go off.

Equal Run Times

With parameter 'Equal Run' (P-27) Set to 1 (On) the controller will bring on the compressors in a way that the running times are as near equal as possible.

If the pressure is above set point, the next compressor that comes on will be the compressor that has been running for the least amount of time.

If the pressure is below set point the next compressor to go off will be the one that has been running the longest.

This configuration will try to make each compressors run hours equal.



Please ensure all power is switched off before installing or maintaining this product.

Fan Reversal

This feature allows a relay to be allocated as a fan reverse signal. This will reverse the condenser fans, once prompted, for a pre-set period to assist clearing debris that may have accumulated in the fans. For the fan reversal relay mapping see [IO mapping](#).

The feature can be activated manually, use a local scheduled time (daily) or wait for a remote command, sent from the Data Manager. When activated, there is an optional delay period (P.603) between the fans stopping and being switched into reverse. Following the delay, the assigned relay will be activated for fan reverse length (P602). During the 'fan reverse' period, the speed of the fans will either be at a fixed value (P.604/ P.605) or varying, depending on current pressures. The fan reversal delay will also be met when returning the fans to 'forward'.

Inverter Bypass

Inverter Bypass Parameter (P-32) is used to set however many retries are required if the Inverter run signal is not returned in the allocated time after the inverter enable has been turned on.

(P-32) set for 1 to 5 is the number of times enable comes on including initial inverter enable turned on.

- 0 = Feature disabled.
- 1 = Inverter enable will come on once with no retries
- 2 = Initial turn on and 1 retry
- 3 = Initial turn on and 2 retries
- 4 = Initial turn on and 3 retries
- 5 = Initial turn on and 4 retries

Firstly assign the desired inverter run input using the Status Fault inputs. This input can be set as either normally closed (INV N/C) or normally open (INV N/O). When the inverter enable relay is called for by the control strategy then the inverter run signal has to be returned to the appropriate input within 2 seconds.

If the run signal is received then the control strategy will continue as normally and the variable output will begin to ramp up.

If the signal is not returned within the allotted time then the following will occur.

(P-32) set for 1 - the inverter enable will stay off and bypass relay will come on.

(P-32) set for 2 to 5 - the inverter enable relay will be turned off for a further 15 seconds.

This process will occur a further 1 to 4 retries depending on (P-32) if the inverter run signal is not received in any test instance. After the retries, the inverter will be taken out of the control logic, until the fault is cleared using the reset process, and the pack will operate as a standard digital pack without the use of the inverter output. At this point the Bypass relay will become like another staged relay and will cycle on and off when called for.

An "INV Bypass" alarm will be generated.

Note: If the inverter run signal is not returned within the allotted time in the first instance but is successful in the second, third or fourth attempt (Depending on P-32), then any future inverter run tests must still complete all tests.

To reinstate the inverter output, once the fault has been rectified, either reset the Plant controller or by using the [Override](#) feature force the relay associated to the inverter on.

The status inputs should be mapped to the relay used as the Inverter Enable relay for a given section i.e. if relay 1 is the first Inverter relay then status Input 1 would become the inverter run input for Section 1. If the second Inverter relay is 5 then status Input 5 would become the inverter run input for Section 2.



Please ensure all power is switched off before installing or maintaining this product.

Relay Run Hours and Relay Starts

The total run hours and the total number of starts for each relay can be viewed via a Laptop/PC (See Stats) or from the Data Manager front end outputs. This feature informs the user of the total number of hours a given relay has been on. Therefore if a compressor is assigned to a relay the total run hours for the compressor can be viewed. It also gives the total number of starts for a given relay. Therefore gives the total number of starts for that compressor.

To reset the run hours and relay starts connect to the controller using PC/ Laptop. Log in and select "Stats" and "Set Parameters" Change the value from "Reset 1" to "Reset 2" or if value is at "Reset 2" change it to "Reset 1" It makes no difference which value is shown, just the operation of changing it from one to the other will reset the run hours and relay starts.

Likewise this can be done from the front end by selecting "Set Parameters" and carrying out the same operation

This applies to all relays including the Alarm relay.



Please ensure all power is switched off before installing or maintaining this product.

Setup via a PC

Log on to the RDM web site and go to Support/ Download Software. Download the driver software/ user guide for your version of Windows and follow the guide to install the necessary USB drivers. A USB cable is required, which connects to a Type-A USB connector (PC) at one end and a Type-B USB connector at the other end (Plant USB Device port). Alternatively if the device is on an IP network type the IP address into an Internet Browser (see [Network setup](#)).

Home page

The home page of the device will show a values page detailing all Inputs, Outputs and states. Additionally there are tabs to the left where users can also view (only) values of specific sections, devices or mapping.

Intuitive Super Pack Resource Data Management

Input	Value	Unit	Output	Value	Unit	State	Value	Unit
S01 Suction Press	3.1	bar	S01 Rly 1	Off		S01 Ctrl State	Normal	
S01 Liq Level	23	%	S01 Rly 2	Off		S02 Ctrl State	High Pressure	
S02 Suction Press	5.0	bar	S01 Rly 3	Off		S03 Ctrl State	Normal	
S03 Disch. Press	7.8	bar	S01 Rly 4	Off				
S03 Probe 1	????????	°C	S01 Var Output	0	%			
			S02 Rly 1	Off				
			S02 Rly 2	Off				
			S02 Rly 3	Off				
			S02 Rly 4	Off				
			S02 Var Output	0	%			
			S03 Rly 1	Off				
			S03 Rly 2	Off				
			S03 Rly 3	Off				
			S03 Rly 4	Off				
			S03 Var Output	0	%			
			S03 Split	Off				

Alarms: 00002 15:06 09/05/2017

Alternatively, if a layout has been uploaded it will be shown. An example is below

Intuitive Super Pack Resource Data Management

Layout

Discharge Pressure: 15.0 bar

EC Fan Output: 90 %

HT Digital Scroll Level: 100 %

HT Comp 1: On
HT Comp 1 Healthy: OK

HT Comp 2: On
HT Comp 2 Healthy: OK

HT Comp 3: On
HT Comp 3 Healthy: OK

HT Suction Pressure: 3.2 bar

Liquid Level: 44 %

LT Comp 1: On
LT Comp 1 Healthy: OK

LT Comp 2: Off
LT Comp 2 Healthy: OK

LT Comp Invert: 0 %

LT Suction Pressure: 1.5 bar

HT Pack Control State: Normal

LT Pack Control State: Normal

Condenser Control State: Normal

Alarms: 00000 12:44 19/05/2017




Please ensure all power is switched off before installing or maintaining this product.

Clicking on the Service icon (cogs), will prompt the user to enter the Username and Password for the device. Default is **install/ 1234**. Setup operations can then be accessed by clicking on the appropriate link from the drop down menus. These menus will look similar to those shown in the [Main Menu Overview \(PC Connection\)](#).

Control

From within the 'Control' menu, the user can select between Section 1, 2 or 3. Each of which offers; Values, Settings, Alarm Log or Set Parameters. The below shows an example of the 'Values' within Section 1. It details the Inputs, Outputs and States.



Link	Operation
Values	Shows the values being returned on the controllers inputs, outputs and state for each section
Settings	Shows the controllers parameter settings for each section
Alarm Log	Shows the controllers alarm history for sections 1, 2, 3: 1000 alarms are stored.
Set Parameters	Set parameters for each section

Alarms

Link	Operation
Current Alarms	Shows the current alarms for all sections.
Old Alarms	Shows the historical alarms for all sections




Please ensure all power is switched off before installing or maintaining this product.

Ct Monitor

From within the 'Ct Monitor' menu, the user can select between Udev (Universal Device) 1, 2 or 3 which allows the compressor currents for each of the 3 sections to be monitored.

Each offers; Values, Settings, Alarm Log or Set Parameters. The below shows an example of the 'Values' within Udev 1. It details the Inputs values and State.



Link	Operation
Values	Shows the values being returned on the controllers CTs
Settings	Shows the controllers parameter settings for each of the CTs
Alarm Log	Shows the controllers alarm history for the CTs
Set Parameters	Set parameters for each section: See Udev setting below

The controller can utilise up to 10 current transformer interface boards (PR0626) each of which can read 5 current transformers with 5A secondaries. These can be used to monitor compressor running current and turn off the associated compressor relay if the current goes over or under the current alarm settings. To reset the compressor relay after an over or under current shutdown, the Proof N/O or Proof N/C input on the relevant section must be activated momentarily. If the section does not have a Proof N/O or Proof N/C input allocated then the current readings will be logged only - Over and under current alarm settings will have no effect.

Udev settings

Within the Set Parameter section of the Udev, the user can set the parameters for up to 5 CTs on each of the 10 CT interface boards.

The CT Pos 1-5 enables the current transformer to be mapped to a particular compressor relay position, position 1 to 16 corresponds to Section 1 compressor relays, 17 to 32 corresponds to Section 2 compressor relays and 33 to 48 corresponds to Section 3 compressor relays.

For each CT, set its range, Low and High Current values with associate Alarm Delay.



Please ensure all power is switched off before installing or maintaining this product.

Mapping

From within the 'Mapping' menu, the user can select between IoMap 1, 2 or 3. Each of which offers; Values, Settings, Alarm Log or Set Parameters. The below shows an example of the 'Settings' within IoMap 1.

Parameter	Value	Board	Position
IO01 PressPos 1	1	Main	1
IO01 PressPos 2	0	Unused	
IO01 PressPos 3	0	Unused	
IO01 PrbPos 1	1	Main	1
IO01 PrbPos 2	0	Unused	
IO01 PrbPos 3	0	Unused	
IO01 PrbPos 4	0	Unused	
IO01 PrbPos 5	0	Unused	
IO01 PrbPos 6	0	Unused	
IO01 PrbPos 7	0	Unused	
IO01 PrbPos 8	0	Unused	
IO01 StatusPos 1	1	Main	1
IO01 StatusPos 2	2	Main	2
IO01 StatusPos 3	3	Main	3
IO01 StatusPos 4	4	Main	4
IO01 StatusPos 5	5	Main	5
IO01 StatusPos 6	0	Unused	
IO01 StatusPos 7	0	Unused	
IO01 StatusPos 8	0	Unused	
IO01 StatusPos 9	0	Unused	
IO01 StatusPos 10	0	Unused	
IO01 StatusPos 11	0	Unused	
IO01 StatusPos 12	0	Unused	
IO01 StatusPos 13	0	Unused	
IO01 StatusPos 14	0	Unused	
IO01 StatusPos 15	0	Unused	
IO01 StatusPos 16	0	Unused	
IO01 InvPos	0	Unused	
IO01 RlyPos 1	1	Main	1
IO01 RlyPos 2	2	Main	2
IO01 RlyPos 3	3	Main	3
IO01 RlyPos 4	4	Main	4
IO01 RlyPos 5	5	Main	5
IO01 RlyPos 6	6	Main	6
IO01 RlyPos 7	0	Unused	

In the example above:

- Section 1 Pressure Position 1 is mapped to Main board Universal Input 1.
- Section 1 Probe Position 1 is mapped to Main board probe input 1.
- Section 1 Status Positions 1 to 5 are mapped to Main board status inputs 1 to 5.
- Section 1 Relay Positions 1 to 6 are mapped to Main board relays 1 to 6.

Link	Operation
Values	Shows the number of I/O that are mapped for each section
Settings	Shows the Inputs and outputs that each section has mapped
Alarm Log	Shows the controllers alarm history for I/O mapping
Set Parameters	Set the I/O Mapping for each section; See: IO Mapping below



Please ensure all power is switched off before installing or maintaining this product.

Note on mapping relays on expansion modules using a local display (PR0615 or PR0620) or a Data Manager

To maintain a standard mapping template for relays, each expansion board can be allocated 12 relay positions, (13 to 24 for example). As the Mini IO expansion module only has 5 physical relays then the next 8 relay positions should be skipped **if** there is another expansion module fitted after the Mini IO. If an Intuitive expansion module (12 relays) is being used as well as a Mini IO expansion module (5 relays) then by having the Mini IO as the last expansion module (highest CANbus rotary address switch position) then any confusion over relay positioning is avoided.

If two Mini IO expansion modules are in use then the relays on the first module would be allocated positions 13 to 17 (relays 1 to 12 are on the main controller), and the relays on the second module would be allocated positions 25 to 29 (13 to 24 are skipped).

This setup only applies when setting the relay mapping using a local display or a Data Manager panel where relay positions are allocated numbers (as shown in the table above).

When using a PC or Touch XL to set up the controller directly then the drop down menus automatically limit the relays available to the relevant expansion module so the above note can be disregarded.

IO Mapping

Map Inputs and Outputs to Main Board or up to 10 Expansion Boards. When setting parameters in sections 1, 2 & 3 above, the inputs and outputs allocated are "virtual" positions, these can be mapped to "physical" positions on the hardware. For example in sections 1, 2 & 3 "virtual" relay position 24 is always the alarm relay but these can be mapped to "physical" relays 8, 9 & 10 for example.

Virtual Relay Position	Pack	Condenser
Relay Positions 1 to 16	Compressor stages (Fixed)	Condenser stages(Fixed)
Relay Position 17	Bypass Relay (If used)	See Relay Positioning Below
Relay Position 18	Gas Dump (If used)	See Relay Positioning Below
Relay Position 19	Not used at present	See Relay Positioning Below
Relay Position 20	Standby Relay (Fixed)	Standby Relay (Fixed)
Relay Position 21	Remote Relay (Fixed)	Remote Relay (Fixed)
Relay Position 22	Offline Relay (Fixed)	Offline Relay (Fixed)
Relay Position 23	Run (Fixed)	Run (Fixed)
Relay Position 24	Alarm Relay (Fixed)	Alarm Relay (Fixed)

All Relay Positions can be mapped to any physical relay on main board or any relay on any expansion board.

Condenser Relay Positions

For sections set as condenser, relays 17-19 change depending on the features enabled. The positions will be taken up using up to 4 features, in order of; Condenser split, Heat Reclaim, Bypass and Fan Reversal.

Example 1 - If condenser uses Split, Heat Reclaim and Bypass;
 Relay Position 17 will be Condenser Split
 Relay Position 18 will be Heat Reclaim Relay
 Relay Position 19 will be Bypass Relay


Example 2 – Condenser uses Heat Reclaim and Fan reversal;
 Relay Position 17 will be Heat Reclaim
 Relay Position 18 will be Fan reversal Relay



Please ensure all power is switched off before installing or maintaining this product.

Stats 1-3

From within the 'Stats' menu, the user can select between Stats 1, 2 or 3. Each of which offers; Values, Settings, Alarm Log or Set Parameters. The below shows an example of the 'Values' within Stats 1.



Link	Operation
Values	Displays the Relay run hours and the relay starts per hour section 1
Settings	Displays the reset Values for each section
Alarm Log	Displays alarm log
Set Parameters	Reset run hours and starts per hour

Visibility

To simplify the appearance of the controller when being viewed with a PC or TouchXL, devices, items, alarms and display values can be hidden or renamed using the Aliases section.

Link	Operation
Device Name Alias	Allows devices to be hidden or renamed such as Section 1, Udev1, IOMap 1, MainBrd1, ExtBrd1 and Stats1, for example Section 1 can be renamed to "HT Pack" or hidden if not used.
Device Item Alias	Allows items within a device to be renamed or hidden such as S01 Press 1, this can be renamed to "HT Suction Press" for example or hidden if not used. There are four subsections or classes, Inputs, Outputs, States and Parameters.
Device Alarm Alias	Allows the description of any alarm to be changed, for example S01 High Pressure can be renamed to "HT Suction High Pressure" or hidden if not used.
Device Display Alias	Allows the text which appears on the remote display (PR0620) to be aliased, for example "HP SEC1" can be changed to "HP SUCT". Characters that can be used are limited by the 8 segment LED display, for example S, A and L can be used but X, Y and Z cannot.
Index Page Display	Allows the user to configure the Inputs (max 30), Outputs (max 60) and States (max 3), that are shown on the homepage.
Active Alarms	Shows a complete list of alarms that can be generated by the Superpack
Hidden Alarms	Shows a list of alarms that are hidden / disabled (e.g. Udev alarms if no Udev devices)

If items are aliased or hidden this will only apply to the controller when viewed directly, all values will be shown when connected to a Data Manager, the Data Manager has its own aliasing page which can be used if required.

To set an alias back to factory setting leave the required field blank and then set aliases.




Please ensure all power is switched off before installing or maintaining this product.


Hardware

Main Board

The Main Board drop down, within the Hardware menu permits the user to; view the real time I/O values being returned, view the current settings for the I/O, view the associated alarm log and the option to set the configuration of the Main Board. An example of the real time I/O is shown below;



Entering the 'Set Parameters' section, it will allow all the Main Board's I/O to be configured, similar to below;




Link	Operation
Values	Shows the values being returned on the main controllers inputs and outputs
Settings	Shows the main controllers configuration settings
Alarm Log	Shows the controllers alarm history; 1000 alarms are stored
Set Parameters	Set the Universal IO, Invert Relay and Probe Offset configuration of the Main Board



Please ensure all power is switched off before installing or maintaining this product.

ExtBrd 1-10

The Extension Board’s hardware set up uses the same method as described in the ‘Main Board’ section above. The one difference refers to the first parameter; “Board”. This option allows the user to detail what board type is being used in this position; select between an IO Expansion Board and a Mini IO board. Examples of both are shown below.



Link	Operation
Values	Shows the values being returned on the controllers Expansion Boards inputs and outputs
Settings	Shows the expansion boards settings
Alarm Log	Shows the expansion boards alarm history; 1000 alarms are stored
Set Parameters	Set the Universal IO, Invert Relay and Probe Offset configuration of the expansion boards

Expansion Board Rotary Switches

Up to 10 expansion boards can be connected to the main controller using a CANbus network cable. The expansion boards are identified by the main controller from their rotary switch position, the **first expansion board should be set to switch position 0**, the second expansion board set to position 1 and so on. The rotary switch is marked as “Module id” on the expansion board.

Override Status

The Override Status menu allows the user to view the current states of the outputs while they are being overridden. It will list the Main Board and any additional Expansion boards attached. Depending on what the setting ‘Override display’ is set to within the [Main Configuration](#) page, it will dictate if any overrides can be made and from which user interface. If any overrides are made, their state will show within these pages.



Please ensure all power is switched off before installing or maintaining this product.

Mapping Summary

This menu provides an overview for each section’s mapping configuration. The example below shows mapping values for configuration PPC (Pack, Pack and Condenser). Section 1 has 6 compressors. Section 2 has 6 compressors. Section 3 has 6 condenser fans.

Section 1 (Pack)				Section 2 (Pack)				Section 3 (Condenser)			
Parameter	Value	Board	Position	Parameter	Value	Board	Position	Parameter	Value	Board	Position
IO01 PressPos 1	1	Main	1	IO02 PressPos 1	9	Ext 1	1	IO03 PressPos 1	17	Ext 2	1
IO01 PressPos 2	0	Unused		IO02 PressPos 2	0	Unused		IO03 PressPos 2	0	Unused	
IO01 PressPos 3	0	Unused		IO02 PressPos 3	9	Ext 1	1	IO03 PressPos 3	0	Unused	
IO01 PrbPos 1	1	Main	1	IO02 PrbPos 1	0	Unused		IO03 PrbPos 1	17	Ext 2	1
IO01 PrbPos 2	0	Unused		IO02 PrbPos 2	0	Unused		IO03 PrbPos 2	18	Ext 2	2
IO01 PrbPos 3	0	Unused		IO02 PrbPos 3	0	Unused		IO03 PrbPos 3	19	Ext 2	3
IO01 PrbPos 4	0	Unused		IO02 PrbPos 4	0	Unused		IO03 PrbPos 4	0	Unused	
IO01 PrbPos 5	0	Unused		IO02 PrbPos 5	0	Unused		IO03 PrbPos 5	0	Unused	
IO01 PrbPos 6	0	Unused		IO02 PrbPos 6	0	Unused		IO03 PrbPos 6	0	Unused	
IO01 PrbPos 7	0	Unused		IO02 PrbPos 7	0	Unused		IO03 PrbPos 7	0	Unused	
IO01 PrbPos 8	0	Unused		IO02 PrbPos 8	0	Unused		IO03 PrbPos 8	0	Unused	
IO01 StatusPos 1	1	Main	1	IO02 StatusPos 1	13	Ext 1	1	IO03 StatusPos 1	20	Ext 1	8
IO01 StatusPos 2	2	Main	2	IO02 StatusPos 2	14	Ext 1	2	IO03 StatusPos 2	20	Ext 1	8
IO01 StatusPos 3	3	Main	3	IO02 StatusPos 3	15	Ext 1	3	IO03 StatusPos 3	20	Ext 1	8
IO01 StatusPos 4	4	Main	4	IO02 StatusPos 4	16	Ext 1	4	IO03 StatusPos 4	20	Ext 1	8
IO01 StatusPos 5	5	Main	5	IO02 StatusPos 5	17	Ext 1	5	IO03 StatusPos 5	20	Ext 1	8
IO01 StatusPos 6	6	Main	6	IO02 StatusPos 6	18	Ext 1	6	IO03 StatusPos 6	20	Ext 1	8
IO01 StatusPos 7	0	Unused		IO02 StatusPos 7	0	Unused		IO03 StatusPos 7	0	Unused	
IO01 StatusPos 8	0	Unused		IO02 StatusPos 8	0	Unused		IO03 StatusPos 8	0	Unused	
IO01 StatusPos 9	0	Unused		IO02 StatusPos 9	0	Unused		IO03 StatusPos 9	0	Unused	
IO01 StatusPos 10	0	Unused		IO02 StatusPos 10	0	Unused		IO03 StatusPos 10	0	Unused	
IO01 StatusPos 11	0	Unused		IO02 StatusPos 11	0	Unused		IO03 StatusPos 11	0	Unused	
IO01 StatusPos 12	0	Unused		IO02 StatusPos 12	0	Unused		IO03 StatusPos 12	0	Unused	
IO01 StatusPos 13	0	Unused		IO02 StatusPos 13	0	Unused		IO03 StatusPos 13	0	Unused	
IO01 StatusPos 14	0	Unused		IO02 StatusPos 14	0	Unused		IO03 StatusPos 14	0	Unused	
IO01 StatusPos 15	0	Unused		IO02 StatusPos 15	0	Unused		IO03 StatusPos 15	0	Unused	
IO01 StatusPos 16	0	Unused		IO02 StatusPos 16	0	Unused		IO03 StatusPos 16	0	Unused	
IO01 InvPos	0	Unused		IO02 InvPos	0	Unused		IO03 InvPos	0	Unused	
IO01 RlyPos 1	1	Main	1	IO02 RlyPos 1	13	Ext 1	1	IO03 RlyPos 1	25	Ext 2	1
IO01 RlyPos 2	2	Main	2	IO02 RlyPos 2	14	Ext 1	2	IO03 RlyPos 2	26	Ext 2	2
IO01 RlyPos 3	3	Main	3	IO02 RlyPos 3	15	Ext 1	3	IO03 RlyPos 3	27	Ext 2	3
IO01 RlyPos 4	4	Main	4	IO02 RlyPos 4	16	Ext 1	4	IO03 RlyPos 4	28	Ext 2	4
IO01 RlyPos 5	5	Main	5	IO02 RlyPos 5	17	Ext 1	5	IO03 RlyPos 5	29	Ext 2	5
IO01 RlyPos 6	6	Main	6	IO02 RlyPos 6	18	Ext 1	6	IO03 RlyPos 6	30	Ext 2	6
IO01 RlyPos 7	0	Unused		IO02 RlyPos 7	0	Unused		IO03 RlyPos 7	0	Unused	

Section 1 (Pack)

- Sect 1 Pressure Position 1 is mapped to Main Board Universal Input 1 (Value = 1. 1st Universal I/O in set up)
- Sect 1 Probe Position 1 is mapped to Main Board Probe Input 1 (Value = 1. 1st Probe input in set up)
- Sect 1 Status Positions 1 to 6 are mapped to Main Board Status Inputs 1 to 6 (Value 1 to 6 1st to 6th Status Inputs in set up)
- Sect 1 Relay Positions 1 to 6 are mapped to Main Board Relays 1 to 6 (Value 1 to 6. 1st to 6th Relays in set up)

Section 2 (Pack)

- Sect 2 Pressure Position 1 is mapped to Expansion Board 1 Universal Input 1 (Value = 9. 9th Universal I/O in set up)
- Sect 2 Probe Position 1 is mapped to Expansion Board 1 Probe Input 1 (Value = 9. 9th Probe input in set up)
- Sect 2 Status Positions 1 to 6 are mapped to Expansion Board 1 Status Inputs 1 to 6 (Value 13 to 18 13th to 18th Status Inputs in set up)
- Sect 2 Relay Positions 1 to 6 are mapped to Expansion Board 1 Relays 1 to 6 (Value 13 to 18. 13th to 18th Relays in set up)

Section 3 (Condenser)

- Sect 3 Pressure Position 1 is mapped to Expansion Board 2 Universal Input 1 (Value = 17. 17th Universal I/O in set up)
- Sect 3 Probe Position 1 to 3 are mapped to Expansion Board 2 Probe Input 1 to 3 (Value = 17, 18, 19. 17th to 19th Probe input in set up)
- Sect 3 Status Positions 1 to 6 are mapped to Expansion Board 2 Status Inputs 1 to 6 (Value 21 to 26. 21st to 26th Status Inputs in set up)
- Sect 3 Relay Positions 1 to 6 are mapped to Expansion Board 2 Relays 1 to 6 (Value 25 to 30. 25th to 30th Relays in set up)

Note: Main Board has 12 status Inputs but Expansion Boards only have 8 each therefore only the first 8 can be used on expansion boards.



Please ensure all power is switched off before installing or maintaining this product.

System

Link	Operation
System Log	Displays the changes made to the controller in chronological order.
Mute All Alarms	Silences all unacknowledged alarms (Yes/No choice).
Clear Alarm Log	Clears the controller alarm log completely (Yes/No choice).
Clear Aliases	Clears all aliases that have been assigned IO. Additionally clears the visibility of sections and IO's.
Features	Displays what features have been enabled on the controller.
Network	Setup: - Rotary Switches (information only) IP Address Netmask Default Gateway
Time	Set the Time or synchronise with the PC.
Version	Shows the controller and expansion board's software version.
TouchXL Status	Displays the IP Address, MAC Address, Name and status of the TouchXL (if connected).



Please ensure all power is switched off before installing or maintaining this product.

Network

BACnet/ RDM-485 Setup

When BACnet has been enabled on the Super Pack (PR0655-BAC), it opens the menu for BACnet configuration. The Intuitive Superpack can communicate over BACnet/IP via it's Ethernet port or by utilising the RDM485 Plant Comms Module (PR0623-DIN-TDB) it can communicate over RS485. Once the below options have been set, the user must then navigate to the '[Main Config](#)' page found in the 'Maintenance' menu and select Network type (XML, BACnet/IP or RDM485) for the controller to communicate over. The below options are available within the BACnet/ RDM-485 configuration page;

BACnet/IP Port	Virtual port number for IP protocol to communicate on. Default 47808.
Device Instance	Unique instance number of the controller, default 280028.
Network Number	Network number the controller is to communicate on. Default 10280.
COV Lifetime	Change of Value period in seconds.
RDM-485 Address	Unique address for the controller while communicating over RDM-485. Default 126.
RDM-485 Speed	Select the RDM-485 network speed; 9600 or 38400.
RDM-485 Max Info Frames	RDM-485 Max Info Frames. Default 1.
RDM-485 Max Master	RDM-485 Max Master. Default 127.
Save Priority	The BACnet priority field is selectable between 1 and 16. It sets the priority level, at which an override with this priority number or above, is treated as a non-volatile parameter 'set' and so will be set and saved as that item's parameter value. So, when set to a value of 8, any override of priority 8-16 will be saved as a parameter.

BacNet Setup

Set BacNet

Configuration	Value
BACnet/IP Port	<input style="width: 80%;" type="text" value="47808"/>
Device Instance	<input style="width: 80%;" type="text" value="280030"/>
Network Number	<input style="width: 80%;" type="text" value="10280"/>
COV Lifetime	<input style="width: 80%;" type="text" value="1800"/>
RDM-485 Address	<input style="width: 80%;" type="text" value="126"/>
RDM-485 Speed	<input style="width: 80%;" type="text" value="9600"/>
RDM-485 Max Info Frames	<input style="width: 80%;" type="text" value="1"/>
RDM-485 Max Master	<input style="width: 80%;" type="text" value="127"/>
Save Priority	<input style="width: 80%;" type="text" value="8"/>
Allow time synch from network	<input style="width: 80%;" type="text" value="UTC/Local"/>

Set BacNet

Allow time synch from network Permits time synchronisation from another networked device.

Note: Only users with a detailed knowledge of the BACnet protocol should amend these details as altering them can have detrimental affects on the communications.




Please ensure all power is switched off before installing or maintaining this product.

Layout

Manage Layouts

The Superpack provides the option for users to upload layouts. Utilising RDM’s Layout Editor software, users can generate their own layout to represent the control strategy in the device. Please consult RDM Technical Support for more details on the Layout Editor. The below shows an example of such a layout;



Link	Operation
Configure	Allows the user to provide a description of the Layout
Set Default	Not used in this variant.
Get	This option allows the layout to be download to the user’s PC.
Remove	Select this option to permanently remove the layout from the Superpack. Note: Once removed the layout cannot be recovered.
Preview	Use this option for a quick view of the selected layout without leaving the setup page.

Note: The current Superpack hardware will support a dynamic image which will only allow one level at a maximum size of 1MB. The new hardware which is due out in the 3rd quarter which will support multiple layers of dynamic images with a much greater size.




Please ensure all power is switched off before installing or maintaining this product.

Maintenance

Link	Operation
Main Config	Allows the configuration of the controller setup. (See information below)
Save Config	Use this option to save the Super Pack configuration to a file
Load Config	Use this option to load the Super Pack configuration to a file
View Config Info	Provides information on the last loaded configuration file and any mismatches
Add Feature	This is a utility to enable features that are currently disabled.
Reset	This allows the user to reset the controller.

Main configuration screen

- Control Type:** Select the [configuration](#) required.
- Num Sections:** Sets how many sections are displayed.
- Probe Type:** Sets probe type being used.
- Press Type:** Sets how pressure is to be displayed.
- Broadcast:** Allows pressure to be broadcast over a Data Manager IP network for use with a Mercury Switch or Mercury IP Module or to broadcast CO2 Case off commands.
- Udev Devices:** This allows the number of USB current monitors being used (1-10) to be set
- Ext Devices:** This allows the number of Expansion boards being used (1-10) to be set
- IP 1 - IP 9:** Current IP address, netmask and gateway.
- Static id:** If rotary switches have been set to 000 this can be used as the broadcasting id.
- Screen Dev:** Determines what information appears on Touch Display Screen (PR0615)
 - Set to option 0 Display items can be manually selected
 - Set to option 1 Displays Section 1-3 info
 - Set to option 2 Displays Current Transformer info
 - Set to option 3 Displays Section 1-3 IO mapping info
 - Set to option 4 Displays Main Board info
 - Set to option 5 Displays Expansion Boards 1-10 info
 - Set to option 6 Displays Section 1-3 Stats
- Network:** When the BACnet feature is enabled, select between; XML; BACIP; XML/BACIP; RDM-485; XML/RDM-485
- Select Tabs:**
 - Off:** Section information tabs not displayed.
 - Web Interface:** Display section information tabs on webpage.
 - Touch:** Displays section information tabs on TouchXL.
 - Web/Touch:** Displays section information tabs on Webpage and TouchXL.
- Override Display:** Provides option for the user to select which interface to permit overrides from. Select from;
 - Off:** Overrides not permitted
 - Plant:** Permits PR0620 remote display.
 - LCD:** Permits the LCD in-built display (if fitted).
 - Touch:** Permits the PR0617-ID TouchXL Display interface.
- Override in HP/LP:** If any overrides are currently active (e.g. compressor relay) and a pressure alarm occurs then the override will be deactivated if set to 'yes'.
- Override Period** : Length of time the override will remain in operation if not manually switched off.
- Config in LCD** : Option to allow user to view/ edit the configuration settings from the LCD screen.
- Auto Split** : Determines whether, when the controller logs onto a DMTouch, if the controller will split (i.e. Section 1, 2 & 3, IO Map 1, 2, & 3, Main Board & Stats 1, 2 & 3) automatically or not.



Note 1 : - The Auto Split parameter MUST be the same, if connecting more than one Superpack to a DMTouch and they are set to the same Control Type.

Note 2 : - If the controller has logged on to a DMTouch and the Auto Split parameter is changed, the Type file must be deleted from the DMTouch



Please ensure all power is switched off before installing or maintaining this product.

Configuration of inputs and outputs

Status Inputs

Section Inputs can be set up as: -

Selection	Selection Name	Description
0	Unused	Input is not used
1	Compressor or Condenser N/O	When selected, "Make" to generate Compressor or Condenser Fault
2	Compressor or Condenser N/C	When selected, "Break" to generate Compressor or Condenser Fault
3	General N/O	When selected, "Make" to generate General Fault
4	General N/C	When selected, "Break" to generate General Fault
5	Standby N/O	When selected, "Make" to place Section 1 into standby and generate Standby alarm.
6	Standby N/C	When selected, "Break" to place Section 1 into standby and generate Standby alarm.
7	Run or Heat Reclaim N/O	When selected, "Break" to use Sect 1 Ext Target (P-13) See Note : Ext Target
8	Run or Heat Reclaim N/C	When selected, "Make" input to use Sect 1 Ext Target (P-13) See Note: Ext Target
9	INV N/O	When selected "Break" to signal Inverter Run. Used when using Inverter Bypass relay. See Note : INV Bypass
10	INV N/C	When selected "Make" to signal Inverter Run. Used when using Inverter Bypass relay. See Note : INV Bypass
11	Proof N/O	When the global Run Proof option is being used, this input is "Make" to reset a compressor trip caused by fault input (options 1 or 2 above) or an over or under current trip.
12	Proof N/C	When the global Run Proof option is being used, this input is "Break" to reset a compressor trip caused by fault input (options 1 or 2 above) or an over or under current trip.

For the above any alarms will be generated after the Status Fault Delay (P.100) has timed out. Note: Standby Alarm has a separate alarm delay (P.102).

Note: These are "Virtual" status inputs so the order in which they are allocated is not important as they will be mapped to actual physical inputs later in the setup. Stages should only be set to unused at the end of allocating, for example Input 1=Comp N/O, Input 2=Comp N/O, Input 3=Comp N/O, Input 4=Standby N/C, Inputs 5 onwards=Unused. Do not set a stage input to Unused followed by used input (such as Comp N/O).



Please ensure all power is switched off before installing or maintaining this product.

External Target

Pack Controller

To use Sect 1/2/3 Ext Target (P-13) instead of Section 1/2/3 Target Pressure (P-09/10) a status Input must be set to "Run 1/2 N/O or N/C".

- When the input is activated the Target Pressure will change from (P-09/10) to (P-13)
- When the input is de-activated the Target Pressure will revert back to (P-09/10)

Condenser Controller Heat Reclaim

Heat Reclaim must be set to "On" or "On/Rly".

To use Sect 1/2 Ext Target (P-13) instead of Target Pressure (P-09/10) a Status Input must be set to "Heat 1/2 N/O or N/C".

With Heat Reclaim parameter (P-98) set to "On" the following will occur: -

- When the input is activated the Target Pressure will change from (P-09/10) Target Pressure to (P-13) Ext Target Pressure
- When the input is de-activated the Target Pressure will revert back to (P-09/10)

Or

With Heat Reclaim parameter (P-98) set to "On/Rly" the following will occur: -

- When input is activated the Target Pressure will change from (P-09/10) to (P-13) and turn on the Heat Reclaim relay output.
- When input is de-activated the Target Pressure will revert back to (P-09/10) and turn off the Heat Reclaim relay output.

Remote TDB Command for Heat Reclaim

To use a Remote Discharge Target Set Point sent from a Data Manager TDB Program Instead of the value entered for the Ext 1/2 Target Pressure (P-13), then the following must be configured: -

- Status Input must be set to "Heat N/O or N/C" and Heat Reclaim has to be set (P-98) to either "On" or "On/Rly".
- When input is activated the Target Pressure will change from (P-09/10) to whatever Target Pressure is being sent from TDB program. The settable range for "S01/02/03 Rem Ext" is -3.4 Bar to 180 Bar.
- When input is de-activated the Target Pressure will revert back to (P-09/10)

Send Ext Target Set Point Command to "S01 Rem Ext", "S02 Rem Ext" or "S03 Rem Ext" using a Data Manager TDB program Analogue Output block.

Note: This command can only be used to change the discharge target and does not apply to the suction target.



Please ensure all power is switched off before installing or maintaining this product.

Section Stages

Pack

#	Stage	Description	Notes
0	None	Use this option to end the number of stages in the controller	
1	Unused	Use this option to skip a stage	
2	Inverter	Use this option to assign a stage to an Inverter	
3	Comp	Use this option to assign a stage output to a compressor	See Note 5 below
4	Loader	Use this option to assign a stage to a compressor loader	See Note 9 below
5	Trim	Use this option to set a stage to a trim compressor	See Note 6 below
6	SSR	Use this option to set a stage to a digital scroll solenoid valve	See Using a Digital Scroll
7	Remote	Use this option to set a stage as remotely controlled from a Data Manager GP Timer or TDB program.	

Condenser

#	Stage	Description	Notes
0	None	Use this option to end the number of stages in the controller	
1	Unused	Use this option to skip a stage	
2	Inverter	Use this option to assign a stage to an Inverter	
3	Fan	Use this option to assign a stage to a fan	
4	Remote	Use this option to set a stage as remotely controlled from a Data Manager GP Timer or TDB program.	

Note 5: In a pack configuration, at least 1 output must be assigned to a compressor. Loader outputs will not energise without a compressor being on. When assigning stages a Loader should follow the Compressor on which it is mounted.

Note 6: This option can be used to provide additional capacity if the inverter capacity is too small. The "Trim" relay will always come on first before the Inverter enable relay and will use the starts per hour parameter. Once the trim stage is on the inverter enable relay would be energised and the inverter analogue output would begin to ramp up. The trim relay would remain on until all other stages are off and the inverter enable relay has been turned off.

Note 9: Relays can be configured as loaders, selected after a compressor stage or a compressor running on an Inverter

Stage Sizes

Stage sizes will determine the order in which compressors or loaders are switched on and off. This is a relative number between 0 and 60, reflecting the size of the compressor (usually horse power).

The default stage size is 0; stage sizes must be entered for correct operation.

Operation (Fuzzy)

Once the controller has been set-up and configured, normal operation will resume. If the appropriate Type has been selected the controller will operate using a "fuzzy logic" based control algorithm. The controller will determine the stages to bring on and off using the fuzzy logic rules and adhering to the starts/hr criteria. The response time for devices switching on and off can be varied by adjusting the response on and response off parameters (1 is the slowest response, 60 is the quickest). The fuzzy logic will attempt to optimise the compressor starts and keep them at a minimum. Before a compressor or fan is switched on, Relay 1 will energise and the variable output will ramp to 100%, when it reaches this point, the fixed device (compressor, loader or fan); will switch on and the variable output will begin its cycle again starting from 0%. When demand is satisfied, and all compressor relays are off, the variable output ramps down 0%, if demand is still satisfied, the enable relay de-energises.



Please ensure all power is switched off before installing or maintaining this product.

Operation (Staged)

Staged operation requires the output relays to be “mapped” to a particular stage. Each stage (there are 16 stages) has to have at least 1 relay assigned for the controller to operate correctly. More than one relay can be assigned to stages in a given section and the same relay can be used in multiple stages. Note a relay cannot be assigned in both Section 1 and Section 2 or 3. As the pressure rises above the target setpoint, plus the target above value, the controller will enter Stage 1 after the stage on delay has expired. At this point any relay assigned in Stage 1 will come on and the stage on delay timer will be reset. If the pressure remains above the setpoint, plus the target above value, and the stage on delay has expired for a second time the controller will enter stage 2. At this point any relay assigned in Stage 2 will come on. Note if a relay has been assigned in Stage 1 but not used in Stage 2 then it will go off at this point. The reverse occurs when the pressure falls below the setpoint plus the target below value. The controller will step down the stages using the stage off delay (P-42) until all stages are off.

When using a variable output as the pressure rises above target setpoint, plus target above, the variable speed output will ramp up from 0% to 100% without following the stage on delay. If the pressure stays above the target setpoint and the variable output is at 100% and the stage on delay has timed out then the controller will enter Stage 1. At this point the variable output will reset to 0% and start ramping up again towards 100%. If the pressure stays above the target setpoint and the variable output is at 100% and the stage on delay has timed out then the controller will enter Stage 2. As the pressure drops below the setpoint, minus the target below, the variable output will ramp from 100% down to 0%, once the stage off delay expires the controller will stage down. Note if the variable output reaches 100% and the stage on delay has not expired the output will remain at 100% until the stage on delay has expired.

For example if set to Pack and pack has 4 Compressors the following could be set:

Sect1 Stg1: Rly 1 = On

Sect1 Stg2: Rly 1 and Rly 2 = On

Sect1 Stg 3: Rly 1, Rly 2 and Rly 3 = On

Sect1 Stg 4: Rly 1, Rly 2, Rly 3 and Rly 4 = On

This would stage relay 1 through to four on after the appropriate stage delay if the pressure is above the target setpoint and differentials.

Other operational features

Floating Head Pressure

When the condenser controller is used in the “Floating Head pressure” mode, the following parameters require to be set up

Set Control Type (P-80) to “Floating”.

Set Float Select (P-81) to Probe 1 to 8 or Remote whichever is monitoring the temperature.

Select the refrigerant being used in the system (P-82).

Set Pressure Type to Gauge or Absolute (P-83).

Condenser Offset (P-86).

The Air On temperature measured added to the condenser offset along with the Gas and Pressure Type is used to profile a pressure curve. This calculated pressure target “Float” replaces the “Target Set Point” (P-09/10) as the target pressure and (P-09/10) is only used as a default; for instance when the probe is disconnected or develops a fault. Low and high pressure levels allow for a lower and upper limit to be set for the pressure range.

The air on temperature can be read from probe inputs 1 to 8 and is settable via parameter P-81. The float temperature can also be received as a TDB command sent from a Data Manager TDB program. This would allow for a single probe temperature to be shared with multiple Plant controllers. Please see the relevant Data Builder user guide with regards to creating a TDB program. The following commands would be used in TDB to send the temperature data to the Plant controller. If P-81 is set to Remote, then “**S01/ S02/ S03 Rem Float**” would be used in the TDB (broadcasting) to send the remote temperature used for Section 1/2/3 condenser float.



Please ensure all power is switched off before installing or maintaining this product.

Drop Leg Control

The condenser sections control type can be configured for 'Drop Leg Control' by selecting the following parameters:

Set Control Type (P-80) to "Drop Leg" (or Drop Leg / Floating Head)

Set Drop Select (P-79) to Probe 1 -8 or 'remote'.

Select the refrigerant being used (P-82)

Set Pressure Type to Gauge or Absolute (P-83)

The temperature from the Drop Leg probe is converted to a pressure (based on the refrigerant type selected), which is used for **control only** in place of the discharge pressure transducer. All other functions, i.e. Low shut down and Discharge trip are based on the discharge pressure transducer. If the drop probe is 'lost', the pressure input reverts back to the discharge pressure transducer and a subsequent probe fault alarm is generated.

The Drop Leg Control probe can be selected from probe inputs 1 to 8, settable via parameter P-79. The Drop Leg temperature can also be received as a TDB command sent from a Data Manager TDB program. Please see the relevant Data Builder user guide with regards to creating a TDB program. The following commands would be used in TDB to send the temperature data to the plant controller. If P-79 is set to 'Remote', then "**S01/ S02/ S03 Rem Drop**" would be used in the TDB (broadcasting) to send the remote temperature to the controller. **Note:** the value will appear in the 'Rem Drop' input.

Night Set-back

This controller, when in condenser mode, has a "Night Set-back" feature for the condenser controller. The variable output can be set to reduce to a pre-determined level, either by; an internal timer, or by times sent to the controller over the network (Use a GP Timer channel in a data Manager).

There is a High pressure limit, over which the night set-back feature will be turned off. As the pressure reduces under this limit the night set-back feature is switched on again.

Day Set-back

Similarly, this controller; when in condenser mode has a day Set-Back feature. The Day Set-Back feature uses the local night Set-Back clock, (if it's out of the night set-back time, day set-back will be on)

Note: - When Set-Back mode is on, no further fan stages will come on unless the variable output reaches 100%, or Set-Back going off.

Invert Relays

The operation of the relays can be inverted so that N/C contacts can be used for energisation. This can be done from the "Main Brd" (d-04) and "Ext Brd" (d-05) sections screen on web page. Choose the relay(s) you wish to invert and set them to on.

This process can also be completed from the controller display. Navigate to the menu option "dEty" and select (d-04) for main board and (d-05) for expansion boards. Select "PArA" and (P-20 to P-31) for relays 1 to 12 for the relay output you wish to invert for example P-24 is relay output 5. Change from "0" to "1" to invert the relay so that the N/C contact is in use.

Note: This operation does not invert the Alarm relays. The alarm relay is energised when there are no alarms present.

Note: All 12 relays on main and expansion boards can be inverted, but if one is selected as an alarm relay take care as you may not want this inverted as it may be best to have it energised when there is no alarm present and de-energised for an alarm state so in the event of a board losing power the alarm relay drops out.



Please ensure all power is switched off before installing or maintaining this product.

Sticky Fans

Sticky fan operation allows the user to turn the fans off in a way that keeps a number of fans running longer.

Example:

If in a Condenser configuration fans are mapped to relays 5, 6, 7, 8, 9, and 10; the following sequence will apply if **sticky fans (P-70) is set to 2:**

	Fan1	Fan2	Fan3	Fan4	Fan5	Fan6
On Sequence	1 st	2 nd	3 rd	4 th	5 th	6 th
Relay #	Relay 5	Relay 6	Relay 7	Relay 8	Relay 9	Relay 10
Off Sequence	6 th	5 th	1 st	2 nd	3 rd	4 th

Remote Relay


The Superpack controller has two forms of remote relay, a pack/condenser stage that is set to remote and a fixed remote relay that is always allocated to relay 21.

Staged Remote Relay

A section stage is set to "Remote" as opposed to "Comp" or "Fan", this relay can be controlled by a Data Manager GP Timer channel or a Data Manager TDB command.

The GP timer channel should be set to "General", the output mask will be the controller device name as it appears on the Data Manager device list and the output channel set to the physical relay number on the controller. The channel number 0 on the GP timer relates to relay 1 on the Superpack controller so to switch relay 12 on the controller the GP timer channel number would be set to 11.

When using a Data Manager TDB program, a digital out block should be used. Under block properties, the device will be the controller device name as it appears on the Data Manager device list and the value will be "S01 Rly 16" as an example. This will control any stage that is set to Remote in section 1 (Relay 16 in this example), the same applies to sections 2 and 3.



In this example of a digital out block in a Data Manager TDB program, the Superpack device name is 222 on the Data Manager and Section 1 relay 16 is set to remote in the Superpack controller.

Fixed Remote Relay: Virtual relay 21 on each section on the Superpack is always a remote relay, this can be mapped to any physical relay on the controller or an expansion board.

This relay can only be remotely controlled using a digital out block in a Data Manager TDB program. Under block properties, the device will be the controller device name as it appears on the Data Manager device list and the value will be "S01 RemRly Cmd". This will control the remote relay in section 1 (S01), the same applies to sections 2 and 3.



Please ensure all power is switched off before installing or maintaining this product.

Viewing Inputs and Outputs

Apart from setting up the controller, you can also view the status of the inputs and outputs.

1. From the function menu, select "IO", press enter
2. You can now scroll through the IO tables as set out below. The tables you view will depend on the controller type configuration.


Input/ Output table (d-01/ Sections)

Note: All sections 1, 2 and 3 has the same I/O numbers.

Number	IO	Range	Units	All Pack Fuzzy	All Pack Staged	All Condenser Fuzzy	All Condenser Staged
I-01	Suction / Discharge Pressure Input 1	-3.4 to 180	Bar	✓	✓	✓	✓
I-02	Pressure Input 2	-3.4 to 180	Bar	✓	✓	✓	✓
I-03	Pressure Input 3	-3.4 to 180	Bar	✓	✓	✓	✓
↓ I-10 I-17	Probe Input 1 ↓ Probe Input 8	-60 to +128	°C	✓	✓	✓	✓
I-30 ↓ I-45	Status Input 1 ↓ Status Input 16	0 = OK 1 = Alarm 2 = Unused	---	✓	✓	✓	✓
I-50	Run	0 = Off 1 = On 2 = Unused	---	✓	✓		
I-54	Liquid Level	0 - 100	%	✓	✓		
I-60 ↓ I-67	Plant Fault 1 ↓ Plant Fault 8	0 = OK 1 = Alarm 2 = Unused	---	✓	✓	✓	✓
I-22	Heat	0 = Off 1 = On 2 = Unused	---			✓	✓
I-23	Remote Ext Target	-3.4 to 180	Bar			✓	✓
I-24	Remote float	-60 to +128	°C			✓	✓
O-01 ↓ O-24	Relay 1 ↓ Relay 24	0 = Off 1 = On	---	✓	✓	✓	✓
O-28	Stage	0-16	----		✓		✓
O-30	Variable Output	0 - 100	%	✓	✓	✓	✓
O-41	Optimisation Level	-3.4 to 180	Bar	✓	✓		
O-51	Float Pressure	-3.4 to 180	Bar			✓	✓
O-55	Split	0 = Off, 1 = On	---			✓	✓
O-56	Heat Reclaim	0 = Off, 1 = On	---			✓	✓
O-61	Night Set-back	0 = Off, 1 = On	---	✓	✓	✓	✓
O-65	Day Set-back	0 = Off, 1 = On	---	✓	✓	✓	✓
O-70	Bypass	0 = Off, 1 = On	---	✓	✓	✓	✓
O-80	Gas Dump	0 = Off, 1 = On	---	✓	✓		
S-01	Control States	0 = Off 1 = Stabilise	---	✓	✓	✓	✓



Please ensure all power is switched off before installing or maintaining this product.

 S-03	2 = Initial 3 = Normal 4 = High Pressure 5 = Low Pressure 6 = Low Shut-down 7 = Transducer Fail 8 = Standby 9 = Trip 10 = Stop					
---	--	--	--	--	--	--

Input/ Output table (d-02/ CT Monitor - UDev)

Number	Inputs Udev	Range	Units
I-01 ↓ I-05	CT1 ↓ CT5	0 to 500	Amps
S-01	U1 State ↓ U10 State	0 = Unused 1 = Offline 2 = Online 3 = Clash	---

Input/ Output table (d-03/ Mapping - I/O Map)

Number	Inputs Map	Range	Units
I-01	Number of Pressure Mapped	0 to 3	---
I-02	Number of Probe Mapped	0 to 8	---
I-03	Number of Status Mapped	0 to 16	---
O-01	Number of Inverters mapped	0 to 1	---
O-02	Number of Relays mapped	0 to 12	---
S-01	S1 State	0 = OK 1 = Alarm	---

Input/ Output table (d-04/ Hardware - Main Board)

Number	Inputs Main Board	Range	Units
I-01 ↓ I-08	M1 Probe 1 ↓ M1 Probe 8	-60 to +128	°C
I-10 ↓ I-17	M1 Uni 1 ↓ M1 Uin 8	0 to 20	---
I-20 ↓ I-31	M1 Status 1 ↓ M1 Status 12	0 = Off. 1 = On	---
O-01 ↓ O-08	M1 Uni1 ↓ M1 Uni8	0 to 20	---
O-10 ↓ O-21	M1 Relay 1 ↓ M1 Relay 12	0 = Off. 1 = On	---



Please ensure all power is switched off before installing or maintaining this product.

Input/ Output table (d-05/ Hardware - Expansion Boards)

Number	Inputs Expansion Board	Range	Units
I-01 ↓ I-08	B1 to B10 Probe 1 ↓ B1 to B10 Probe 8	-60 to +128	°C
I-10 ↓ I-17	B1 to B10 Uni 1 ↓ B1 to B10 Uni 8	0 to 20	---
I-20 ↓ I-27	B1 to B10 Status 1 ↓ B1 to B10 Status 8	0 = Off. 1 = On	---
O-01 ↓ O-08	B1 to B10 Uni1 ↓ B1 to B10 Uni8	0 to 20	---
O-10 ↓ O-21	B1 to B10 Relay 1 ↓ B1 to B10 Relay 12	0 = Off. 1 = On	---
S-01	B1 to B10	0 = Unused 1 = Offline 2 = Invalid 3 = Mismatch 4 = Reset 5 = Normal	

Input/ Output table (d-06/ Stats)

Number	Inputs Expansion Board	Range	Units
O-01 ↓ O-24	Relay 1 Run Hours ↓ Relay 24 Run Hours	0 to 32767	Hours
O-30 ↓ O-53	Relay Starts 1 ↓ Relay Starts 24	0 to 32767	---

Quick View (PR0620 Remote Display)

Pressing the "quick view" button during normal operation displays the target pressures. Repeated presses will scroll through section 1 then section 2 and section 3 target pressures.

Info Button (PR0620 Remote Display)

Pressing the "info" button during normal operation displays the number of current alarms. Repeated presses will scroll through section 1 then section 2 and section 3 number of current alarms



Please ensure all power is switched off before installing or maintaining this product.

Display Messages

The following messages can appear on the display during normal operation.

Display	System status
HP	High Pressure alarm (Pack or Condenser)
LP	Low Pressure alarm (Pack or Condenser)
Sd	Low Pressure Shut-down (Pack or Condenser)
Lh 1 to Lh 3	Liquid Level High Level alarm
LL 1 to LL 3	Liquid Level Low Alarm
LF 1 to LF 3	Liquid Level Fault
Inv 1 to Inv 3	Inverter Fault
trAn Ft	Pressure Transducer Fault
St 1 to St 16	Stage 1 to 16 Fault (Comp or Cond)
gn 1 to gn 16	General Fault
Stby	Controller in Standby
triP	Discharge Pressure Trip / Stop
br 1 to br 10	Board Offline Alarm
rCL1 to rCL3	Relay Mapping Clash

Note 10: If Only 1 Transducer is fitted and the controller is set to a single section type, for example Pack, then Display 1 will show the current suction pressure and Display 2 will show Sec 1.

If Only 2 Transducers are fitted and the controller is set to a dual section type, for example Pack and Condenser, then Display 1 will alternate between section 1 and 2 pressures and Display 2 will alternate between Sec 1 and Sec 2 for whatever pressure is being displayed

Override Function

The Outputs from the Super Pack Controller (and expansions) can be overridden from specified displays, setup within the [Main Configuration](#) Page.

Overrides - PR0620 Remote Display

Pressing the 'override' button during normal operation displays the variable output value. Repeated presses will scroll through section 1 then section 2 and section 3 variable output values.

When the parameter 'Override Display' is set to 'Plant' within the [Main Configuration](#) page, the override function from the Plant Display (PR0620) is permitted. This allows the user to switch output stages on or off:

- Press the override and enter button together for approximately 3 seconds until "t-01" is displayed.
- "t-01" = main board.
- "t-02" - "t-11" = Ext board 1 to 10.
- Press enter to go to "Main Board" (t-01) overrides.
- "r-01" will be displayed.
- Use the "up" or "down" button to display the relays (r-01 to r-12) and analogue outputs (A-01 and A-08).
- For r-01 to r-12, press "Enter" and select "1" to turn the relay on and "0" to turn the relay off.
- For A-01 to A-08, press "Enter" and use up and down buttons to select the desired output percentage.
- Press the "Enter" button when the desired value is reached. Each output can be set between 0% - 100%.

Note: A-01 to A-08 must be set for variable outputs. Overrides will last for the period set within the Main Configuration pages then the output will return to normal operation.



Please ensure all power is switched off before installing or maintaining this product.

Overrides - LCD in-built Display

When the parameter 'Override Display' is set to 'LCD' within the [Main Configuration](#) page, the override function from the in-built LCD screen (if fitted) is permitted. This allows the user to switch output stages on or off:

- From the main menu within the LCD, scroll down to select the Overrides menu.
- Select the device. Depending on the setup it will list the Main Board and number of Expansion devices.
- Scroll down through the pages to find the desired output and press Enter.
- Scroll to the output to override and press Enter.
- When the current state of the output is shown, use the arrow keys to change its state. E.g. OverrideOn, OverrideOff if overriding a relay or a % for a variable output.
- Press Enter to confirm.

Note: A-01 to A-08 must be set for variable outputs. Overrides will last for the period set within the Main Configuration pages then the output will return to normal operation.

Overrides – Touch Display

When the parameter 'Override Display' is set to 'Touch' within the [Main Configuration](#) page, the override function from the Touch screen (if fitted) is permitted. This allows the user to switch output stages on or off:

Standby Mode

Once in standby all configured stages are turned off and a standby alarm is generated for the given section. There is a settable delay (P.102) before a section enters standby. Once this delay expires the controller enters standby and an alarm is generated for the relevant section.

Section 1, 2 and 3 can be placed into standby independently using three separate status inputs. Else, 1, 2 or 3 sections can be placed into standby using a common status input by mapping one physical input to each section.

Network Alarms

The table below shows the text and associated type number that is sent to the system "front end". The type number is normally used to provide different alarm actions.

Alarm text	Type #
High Pressure Alarms	8
Low Pressure Alarms	9
Low Pressure Shutdown	10
Transducer Faults	6
Discharge Trip	8
General Faults	20
Stage Faults	3
Inverter Fault	3
Board Offline	20

Alarm text	Type #
Float Probe Fault	6
Liquid Level Fault	6
Liquid Level High	4
Liquid Level Low	5
Controller in standby	20
CT High Amp	16
CT Low Amp	17
CT Offline	6



Please ensure all power is switched off before installing or maintaining this product.

Specification

Power requirements (for each Main Controller or expansion module)

Supply Voltage Range	24 Vac $\pm 10\%$ or 24 Vdc $\pm 10\%$
Supply Frequency	50 - 60 Hz $\pm 10\%$
Maximum supply current	<1 Amp
Typical supply current	0.3 Amp
Class 2 Insulation	No protective Earth is required. A functional earth can be connected if the equipment is located in an electrically noisy environment.

Note: The use of centre tapped to earth transformers is not allowed. This is to prevent damage to the transformer and/or controller. The host equipment must provide adequate protection against contact to hazardous live parts.

RDM advise the use of a suitable external over-current protection device on the Mercury Plant Controller.

Warranty may be invalidated due to excess current being unlimited if there are no fuses/circuit breakers installed.

General

Operating temperature range	-10°C to +60°C
Operating Humidity	80% maximum
Storage temperature range	-20°C to +65°C
Environmental	Indoor use at altitudes up to 2000m, Pollution Degree 1, Installation Category II. Voltage fluctuations not to exceed $\pm 10\%$ of nominal voltage
Dimensions	Intuitive Plant Controller 280mm (L) x 122mm (W) x 67mm (H)
Weight	Intuitive Plant Controller 750 Grams
Safety	EN61010
EMC	EN61326; 1997 +Amdt. A1; 1998
Ventilation	There is no requirement for forced cooling ventilation

Inputs

Probe Input type	See Set/change Units for probe types
Status Input type	The preferred option is a 0 volt return through a volt free relay or 24 Vac referenced to the supply voltage. If a 24Vac signal is being sourced from the Plant controller power supply then do not ground the Status Input common rail, this is grounded internally.
4-20mA	4-20mA current loop, use the 12 Vdc output to feed the device.

Outputs

Analogue Outputs	0-10 Volts DC or 4-20mA. (Selected in properties box of the output block)
Note 1	The 4-20mA output will not operate correctly if the target device input impedance is $> 75\Omega$
Note 2	The 0-10V output will not operate correctly if the target device input impedance is $< 10K\Omega$ A 50mA fuse is recommended for this output.
Note 3	On the intuitive variant, when using the universal 0-10V output to drive an inductive load such as a relay coil, a back e.m.f. protection diode must be fitted. The cathode should connect to the output terminal and the Anode to GND/Return terminal. The maximum load current that can be supplied from these outputs is 38mA. The mercury plant cannot be used to drive a relay coil.
Relay Ratings, Intuitive Plant Controller	
Mechanical Relay	10A/250 Vac/AC1 (Resistive load)
	10A/30 Vdc (Resistive load)



Please ensure all power is switched off before installing or maintaining this product.

	5A/250 Vac $\cos\phi=0.4$
Solid State Relay (SSR)	1A/250 Vac (AC only, will not switch DC)
Fuse Ratings, Intuitive Plant Controller	
	Relay Fuses 10A Anti-surge HRC, 32 x 6.3mm (1A if SSR is fitted)
	Supply Fuse 2A Antisurge HRC, 32 x 6.3mm

Comms

Comms	Ethernet
Inter-board Comms	CANbus (see specification below)

CANbus cable specification


CANbus communication cable **must** be of a standard to meet ISO11898 or equivalent and the screen cable **must** be connected.

Firstly wire the CANbus network from the controller to each Expansion board. The Intuitive Controller has a termination resistor built in which is selected by a jumper. The network should be wired in a daisy chain configuration. Only one Intuitive Plant controller should be connected to a single CANbus network. The maximum allowable network cable length is 500M in total from one end of the network to the other providing a CANbus network cable which meets ISO11898 or equivalent is used.

A maximum of 10 expansion boards can be connected to a single Intuitive Plant controller. When connecting an expansion board to an Intuitive Plant controller or another Expansion board the following must be observed.

Plant Controller/Expansion Board		Expansion Board
CAN High	Connects to	CAN High
Screen	Connects to	Screen
CAN Low	Connects to	CAN Low
Ground	Connects to	Ground

End of line termination resistor




The end of line termination resistor link should be fitted to the middle and bottom pins on the Main control board and on the last expansion board on the CANbus network. All other expansion boards should have the link removed or fitted to the middle and top pins.



Please ensure all power is switched off before installing or maintaining this product.


Installation

Mounting on to a DIN rail, Intuitive Plant Controller



The Intuitive plant controller has three DIN rail mounting feet which can slide in and out to three different positions, sliding into each position is accompanied by a “click” which locks the foot into that position.

To install the controller onto a DIN mounting rail, from the fully pushed in position slide the top mounting foot out by 2 clicks so that the foot is clear of the DIN rail channel. Slide the bottom two feet out by one click so that they are protruding slightly into the DIN rail channel. The controller can now be inserted onto the DIN rail by inserting the bottom lip of the DIN rail behind the two bottom mounting feet



The controller can now be pushed flat onto the DIN rail and the top foot pushed in 2 clicks to hold the controller in place. Finally, push the bottom two feet in by one click to secure the controller.

The mounting feet also have M3 holes for direct mounting where DIN rail is not being used.

Clearances

The controller requires 40mm clearance top and bottom to allow fuse access and removal and USB cable connection, otherwise 10mm is required, side clearance is 15mm. Clearance at the front and rear is dependent on the site wiring.

There is no requirement for forced cooling ventilation



Please ensure all power is switched off before installing or maintaining this product.

Cleaning

Do not wet the controller when cleaning. Clean the front by wiping with a slightly dampened lint free cloth.

Please note: The specifications of the product detailed on this set up guide may change without notice. RDM Ltd shall not be liable for errors or for incidental or consequential damages, directly or indirectly, in connection with the furnishing, performance or misuse of this product or document.




Please ensure all power is switched off before installing or maintaining this product.

Appendix 1 – Supply & Status Input Wiring

Appendix four applies to the current version of the Plant controller hardware.

- Method 1. Uses the 24Vac of the transformer supplying the input voltage; which is returned via a switch (or relay) to the status input signal line. No 0V is required at the status connector.
- Method 2. Uses a 0V return (from the status connector) to the status signal input.
- Method 3. Uses a 24Vac signal derived from another transformer (supplying an auxiliary piece of kit) to feed the status input signal line. Note the auxiliary transformer must be referenced to the Plant Controller supply transformer.

All transformers that have a connection to the Plant Controller must have their primaries connected to the same phase. Transformer should have fuse fitted in line with 24V input as per diagram.



The use of centre tapped to earth transformers is not allowed. This is to prevent damage to the transformer and/or controller.

Appendix 2 – Data Manager Load Shedding Setup

Typical Data Manager Load shedding settings are shown below when using a Superpack controller:

- Pressure device:** This should be entered a "\$Pack001" where 001 is the network address of the controller (usually the rotary switch positions).
- Pressure Item:** This can be Press1, Press2 or Press3 and relates to which of the pressure transducers on that section you want to use.
- Pack Type:** This can be set to New (Section1), New (Section 2) or New (Section3) depending on which section you want to use.

Other settings:			
Ambient Temperature Device	-----	Load Pressure Limit 1	50
Ambient Temperature Input	-----	Load Pressure Diff	5
Pressure Device	\$Pack001	Load Pressure Time 1 (s)	20
Pressure Item	Press1	Load Pressure Limit 2	55
Pack Type	New (Section 1)	Load Pressure Time 2 (s)	20
		Load Pressure Start Stage 2	2



Please ensure all power is switched off before installing or maintaining this product.

Appendix 3 – BACnet object list.

The BACnet object list can be viewed by appending "bacnet.xml" to the end of the device's IP address in the browser address bar, for example;

<http://10.255.255.254/bacnet.xml>

This list will vary depending on controller setup and type. An example is shown below:

```
<?xml version="1.0"?>
- <CONTROLLER>
  <VENDOR>Resource Data Management</VENDOR>
  <ID>684</ID>
  <DEVICE>2272300</DEVICE>
  <NAME>Intuitive SuPack</NAME>
  <TYPE>FTYPE_PPC</TYPE>
  <VER>V2.4</VER>
- <OBJECTS>
  <Obj RES="0.10" UNITS="bar" MAX="180.00" MIN="-3.40" TYPE="ANALOG_INPUT" NAME="S01 Suction Press"
    INS="obj_0">26.60</Obj>
  <Obj RES="0.10" UNITS="bar" MAX="180.00" MIN="-3.40" TYPE="ANALOG_INPUT" NAME="S01 Press 1"
    INS="obj_1">71.00</Obj>
  <Obj RES="0.10" UNITS="bar" MAX="180.00" MIN="-3.40" TYPE="ANALOG_INPUT" NAME="S01 Press 2" INS="obj_2">
    nan</Obj>
  <Obj RES="0.10" UNITS="C" MAX="256.00" MIN="-60.00" TYPE="ANALOG_INPUT" NAME="S01 Probe 1" INS="obj_3">
    nan</Obj>
  <Obj RES="0.10" UNITS="C" MAX="256.00" MIN="-60.00" TYPE="ANALOG_INPUT" NAME="S01 Probe 2" INS="obj_4">
    nan</Obj>
  <Obj RES="0.10" UNITS="C" MAX="256.00" MIN="-60.00" TYPE="ANALOG_INPUT" NAME="S01 Probe 3" INS="obj_5">
    nan</Obj>
  <Obj RES="0.10" UNITS="C" MAX="256.00" MIN="-60.00" TYPE="ANALOG_INPUT" NAME="S01 Probe 4" INS="obj_6">
    nan</Obj>
  <Obj RES="0.10" UNITS="C" MAX="256.00" MIN="-60.00" TYPE="ANALOG_INPUT" NAME="S01 Probe 5" INS="obj_7">
    nan</Obj>
  <Obj RES="0.10" UNITS="C" MAX="256.00" MIN="-60.00" TYPE="ANALOG_INPUT" NAME="S01 Probe 6" INS="obj_8">
    nan</Obj>
  <Obj RES="0.10" UNITS="C" MAX="256.00" MIN="-60.00" TYPE="ANALOG_INPUT" NAME="S01 Probe 7" INS="obj_9">
    nan</Obj>
  <Obj RES="0.10" UNITS="C" MAX="256.00" MIN="-60.00" TYPE="ANALOG_INPUT" NAME="S01 Probe 8"
    INS="obj_10"> nan</Obj>
  <Obj TYPE="MULTI_STATE_INPUT" NAME="S01 Status 1" INS="obj_11" VALS="OK | Alarm | Unused">OK</Obj>
  <Obj TYPE="MULTI_STATE_INPUT" NAME="S01 Status 2" INS="obj_12" VALS="OK | Alarm | Unused">Alarm</Obj>
  <Obj TYPE="MULTI_STATE_INPUT" NAME="S01 Status 3" INS="obj_13" VALS="OK | Alarm | Unused">Alarm</Obj>
  <Obj TYPE="MULTI_STATE_INPUT" NAME="S01 Status 4" INS="obj_14" VALS="OK | Alarm | Unused">Alarm</Obj>
  <Obj TYPE="MULTI_STATE_INPUT" NAME="S01 Status 5" INS="obj_15" VALS="OK | Alarm | Unused">Alarm</Obj>
  <Obj TYPE="MULTI_STATE_INPUT" NAME="S01 Status 6" INS="obj_16" VALS="OK | Alarm | Unused">Alarm</Obj>
  <Obj TYPE="MULTI_STATE_INPUT" NAME="S01 Status 7" INS="obj_17" VALS="OK | Alarm | Unused">Alarm</Obj>
  <Obj TYPE="MULTI_STATE_INPUT" NAME="S01 Status 8" INS="obj_18" VALS="OK | Alarm | Unused">Unused</Obj>
  <Obj TYPE="MULTI_STATE_INPUT" NAME="S01 Status 9" INS="obj_19" VALS="OK | Alarm | Unused">Unused</Obj>
  <Obj TYPE="MULTI_STATE_INPUT" NAME="S01 Status 10" INS="obj_20" VALS="OK | Alarm |
    Unused">Unused</Obj>
  <Obj TYPE="MULTI_STATE_INPUT" NAME="S01 Status 11" INS="obj_21" VALS="OK | Alarm |
```

Disclaimer

The specifications of the product detailed in this document may change without notice. RDM Ltd shall not be liable for errors or omissions, for incidental or consequential damages, directly or indirectly, in connection with the furnishing, performance or misuse of this product or document.



Please ensure all power is switched off before installing or maintaining this product.

Revision History

Revision	Date	Changes
1.0	01/05/2013	First Issue
1.1	23/08/2013	Clarification of status input allocation.
1.2	22/10/2013	Run proof reset description corrected.
1.2a	09/01/2014	Scroll compressor added, inverter starts per hour, discharge temperature shutdown, fuzzy weighting, aliasing and hiding parameters, standby delay.
1.2b	17/01/2014	Clearances increased to cover fuses and USB lead, PR0661 expansion part number added.
1.3	27/01/2014	Discharge temperature differential parameter (P-67) added, discharge stop now only stops the digital scroll.
1.5	18/02/2014	Separate pressure unit's field added to configuration page.
1.5a	06/06/2014	0.5-4.5v and 0.5-9.5v Universal input parameters added, relay positions clarified.
1.6	03/08/2014	Broadcast added for pack optimisation.
1.7	26/08/2014	Inverter output on section 2 modified.
1.8	12/09/2014	Clarification of Floating head pressure when condenser section not in use.
1.8a	10/11/2014	Clarification of CANbus connection.
1.9	18/12/2014	Operating temperature range amended.
2.1	31/08/2015	New features: Fan Reversal, Drop Leg control, standby relay.
2.2	20/09/2015	Improvements to USB memory stick interaction.
2.3	19/10/2015	Custom Touch display screen are now saved in the configuration.
2.4	20/11/2015	BACnet added, number of sections, Udev and expansion board parameters added, universal IO default to 0-10v In.
2.5	07/01/2015	Improvement to PID inverter operation when output maximum is set to less than 100%.
2.5a	26/01/2016	Description of Digital/Status Inputs standardised to Status Inputs.
2.6	03/03/2016	Fan reverse level parameter added.
2.7	23/03/2016	Touchscreen item mapping feature added.
2.8	28/07/2016	Mini I/O expansion board support added, discharge trip default increased from 15 to 16 Bar.
2.8a	20/08/2016	Update to specification page.
2.9	22/09/2016	Text characters changed on hyphens to be compatible with Touchscreen.
3.0	12/12/2016	Remote heat recovery TDB commands added.
3.1	20/12/2016	Plant Fault Inputs I-60 to I-67 added to IO table, note on split condenser added.
3.2	18/01/2017	Fan Interlock parameter added.
3.3	07/06/2017	New cgi interface, layout menu added, split condenser modes added, remote relay added, refrigerant weighting parameter added, 1-2V, 1-6V inputs added, 1-5V output added, View Config Info Menu added.
3.3a	25/08/2017	Refrigerant table updated.
3.4	08/11/2017	Note added regarding use of digital scroll compressor when set to Staged type. Improvement to Inverter response.
3.7	02/02/2018	Revision level updated to keep in line with the V2 platform.
3.8	16/02/2018	Universal inputs limitation, Override options and visibility page added
3.9	01/06/2018	New Auto-Split feature used with DMT, Added New LCD Menu, USB options added to LCD menus, New Override options for the Main & Expansion Boards, Added Override Options in Config, Aliased and hidden items carried through to LCD display.
4.0	03/07/2018	Improvement to relay overrides.
4.1	13/07/2018	Improvement of built in display operation.
4.2	26/07/2018	Protection improved for uploading files through USB.
4.3	21/08/2018	Enhancements made for handling of configuration files.



Please ensure all power is switched off before installing or maintaining this product.

Group Offices

RDM Group Head Office

80 Johnstone Avenue
Hillington Industrial Estate
Glasgow
G52 4NZ
United Kingdom

+44 (0)141 810 2828

support@resourcedm.com

RDM Inc

100 North Sixth Street
Suite 630B
Minneapolis, MN
55403
United States

+1 612 354 3923

usasupport@resourcedm.com

RDM Asia

Sky Park at One City
Jalan USJ 25/1
47650 Subang Jaya
Selangor
Malaysia

+603 5022 3188

info@rdmasia.com.my



Visit www.resourcedm.com/support for more information on RDM solutions, additional product documentation and software downloads.

While every effort is made to ensure the information given within this document is accurate, Resource Data Management Ltd shall not be liable for errors or omissions, for incidental or consequential damages, directly or indirectly, in connection with the furnishing, performance or misuse of this product or document. All specifications are subject to change without notice.

See www.resourcedm.com for terms and conditions of sales.

Copyright © Resource Data Management