


Mercury Displays

Mercury Remote Displays

- **Mercury Remote Display** (complete with 5 metre cable) **PR0325**
- **Mercury Remote Display with Keyswitch** (complete with 5 metre cable) **PR0326**
- **Mercury DIN Display** (no cable) **PR0327**
- **Mercury DIN Display with Keyswitch** (no cable) **PR0328**
- **Mounting Collar for PR0325 & PR0326** **PR0329**
- **5 metre cable for PR0327 & PR0328** **PR0324**


Mercury Remote Display with Keyswitch



Panel Cut-out

PR0325 & PR0326 are supplied complete with a 5 metre cable with the appropriate connector for Mercury controllers

Mercury DIN Display with Keyswitch



Panel Cut-out 89mm x 43,5mm

PR0327 & PR0328 require a cable (PR0324). PR0324 is supplied complete with appropriate connectors for the display and controller.

These are generic displays, for specific keyswitch functions; refer to the controller user/installation guides.

Resource Data Management
80 Johnstone Avenue
Hillington
Glasgow
G52 4NZ

Tel: 0141-810-2828
Fax: 0141-810-2829
sales@resourcedm.com
www.resourcedm.com

Please note: The specifications of the product detailed on this data sheet may change without notice. RDM Ltd shall not be liable for errors or for incidental or consequential damages, directly or indirectly, in connection with the furnishing, performance or misuse of this product or document.